DEPARTMENT OF TRANSPORTATION R DATE: FEDERAL AVIATION ADMINISTRATION

Revision: 38 Date: 11/14/90

WASHINGTON, D.C.

MASTER MINIMUM EQUIPMENT LIST

B-707 AND B-720

Federal Aviation Administration Flight Standards Division AIRCRAFT EVALUATION OFFICE (AEO), ANM-270S 1601 Lind Ave. S.W.

Renton, Washington 98055-4056

Telephone: Comm: (206) 227-2280 FTS: 392-2280

FEDERAL AVIATION ADMINISTRATION Page: I

MASTER MINIMUM EQUIPMENT LIST Date: 11/14/90

Page: 1 Revision: 38 Date: 11/14/90

B-707 AND B-720

Table of Contents

SYSTEM NO. SYSTEM

PAGE

	Table of Contents	I
	Log of Revisions	II
	Control Page	III, IV, V
	Highlights of Change	VI
	Definitions	VII, VIII, IX, X
	Definitions	XI, XII
	Preamble	XIII, XIV
21	Air Conditioning	21-1, 2, 3, 4, 5
21	Air Conditioning	21-6 THRU 10
21	Air Conditioning	21-11
22	Auto Flight	22-1
23	Communications	23-1, 2
24	Electrical Power	24-1, 2, 3
25	Equipment/Furnishings	25-1, 2, 3, 4
26	Fire Protection	26-1, 2, 3, 4
27	Flight Controls	27-1, 2
28	Fuel	28-1, 2, 3, 4, 5
28	Fuel	28-6, 7
29	Hydraulic Power	29-1, 2, 3
30	Ice and Rain Protection	30-1, 2, 3, 4, 5
31	Indicating/Recording Systems	31-1
32	Landing Gear	32-1
33	Lights	33-1, 2, 3, 4, 5
34	Navigation	34-1, 2, 3, 4, 5
34	Navigation	34-6
35	Oxygen	35-1, 2
36	Pneumatic	36-1
52	Doors	52-1, 2
53	Fuselage	53-1
73	Engine Fuel & Control	73-1
74	Ignition	74-1
77	Engine Indicating	77-1, 2
78	Engine Exhaust	78-1
79	Engine Oil	79-1
82	Water Injection	82-1

FEDERAL AVIATION ADMINISTRATION Page: II Revision: 38 MASTER MINIMUM EQUIPMENT LIST Date: 11/14/90

B-707 AND B-720

Log of Revisions

 REV.NO.	DATE	PAGE NUMBERS	INITIALS
38 38 38 38 38 	11/14/90 11/14/90 11/14/90 11/14/90 	<pre>HIGHLIGHTS OF REV.,DEFINITIONS PREAMBLE 23-2,25-1,25-4,31-1,33-1 33-2,34-5,34-6 </pre>	

FEDERAL AVIATION ADMINISTRATION Page: III

Revision: 38MASTER MINIMUM EQUIPMENT LISTDate: 11/14/90

B-707 AND B-720

Control Page

SYSTEM	PAGE	REV NO.	CURRENT DATE
Cover Page	_	38	11/14/90
Table of Contents	I	38	11/14/90
Log of Revisions	II	38	11/14/90
Control Page	III	38	11/14/90
concror rage	IV	38	11/14/90
	V	38	11/14/90
Highlights of Change	VI	38	11/14/90
Definitions	VII	3	10/02/89
201111010115	VIII	3	10/02/89
	IX	3	10/02/89
	X	3	10/02/89
	XI	3	10/02/89
	XII	3	10/02/89
Preamble	XIII	2	06/14/89
	XIV	2	06/14/89
21	21-1	37	10/19/90
	21-2	37	10/19/90
	21-3	37	10/19/90
	21-4	37	10/19/90
	21-5	37	10/19/90
	21-6	37	10/19/90
	21-7	37	10/19/90
	21-8	37	10/19/90
	21-9	37	10/19/90
	21-10	37	10/19/90
	21-11	37	10/19/90
22	22-1	37	10/19/90
23	23-1	37	10/19/90
	23-2	38	11/14/90
24	24-1	37	10/19/90
	24-2	37	10/19/90
	24-3	37	10/19/90
25	25-1	38	11/14/90
	25-2	37	10/19/90
	25-3	37	10/19/90
	25-4	38	11/14/90
26	26-1	37	10/19/90
	26-2	37	10/19/90
	26-3	37	10/19/90
	26-4	37	10/19/90

FEDERAL AVIATION ADMINISTRATION Page: IV

MASTER MINIMUM EQUIPMENT LIST Date: 11/14/90

Revision: 38

B-707 AND B-720

Control Page

SYSTEM	PAGE	REV NO.	CURRENT DATE
27	27-1	37	10/19/90
	27-2	37	10/19/90
28	28-1	37	10/19/90
	28-2	37	10/19/90
	28-3	37	10/19/90
	28-4	37	10/19/90
	28-5	37	10/19/90
	28-6	37	10/19/90
	28-7	37	10/19/90
29	29-1	37	10/19/90
	29-2	37	10/19/90
	29-3	37	10/19/90
30	30-1	37	10/19/90
	30-2	37	10/19/90
	30-3	37	10/19/90
	30-4	37	10/19/90
	30-5	37	10/19/90
31	31-1	38	11/14/90
32	32-1	37	10/19/90
33	33-1	38	11/14/90
	33-2	38	11/14/90
	33-3	37	10/19/90
	33-4	37	10/19/90
	33-5	37	10/19/90
34	34-1	37	10/19/90
	34-2	37	10/19/90
	34-3	37	10/19/90
	34-4	37	10/19/90
	34-5	38	11/14/90
	34-6	38	11/14/90
35	35-1	37	10/19/90
	35-2	37	10/19/90
36	36-1	37	10/19/90
52	52-1	37	10/19/90
	52-2	37	10/19/90
53	53-1	37	10/19/90
73	73-1	37	10/19/90
74	74-1	37	10/19/90
77	77-1	37	10/19/90
	77-2	37	10/19/90

FEDERAL AVIATION ADMINISTRATION Page: V Revision: 38

MASTER MINIMUM EQUIPMENT LIST Date: 11/14/90

B-707 AND B-720

Control Page

SYSTEM	PAGE	REV NO.	CURRENT DATE
78	78-1	37	10/19/90
79	79-1	37	10/19/90
82	82-1	37	10/19/90

FEDERAL AVIATION ADMINISTRATION Page: VI Revision: 38 MASTER MINIMUM EQUIPMENT LIST Date: 11/14/90

B-707 AND B-720

Highlights of Change 38

EFFECTIVE ABOVE DATE, The B-707/B-720 Master Minimum Equipment List has been revised. Change bars have been utilized to indicate any change from Revision 37. Changes to ATA sytems beyond minor technical and formatting changes are annotated in the highlights. Please retain this section for future reference.

ATA 23 COMMUNICATIONS

Item 9: Category changed from B to A.

ATA 25 EQUIPMENT/FURNISHINGS

Item 1: Subpart 1) Category changed from B to C, Subpart 2) deleted, and proviso revised for clarity.

Item 11: Subpart 1) added.

ATA 31 INDICATING/RECORDING SYSTEMS

Item 2: Category changed from B to A.

ATA 33 LIGHTS

Item 2: Provisos reworded for clarity and to include provisions for lavatories. Subpart 1) added.

Page 33-2: New page - no changes.

ATA 34 NAVIGATION

Item 32: Revised to include provisions for glideslope deviation lights and Mode 6 warning.

Item 35: Format and minor word changes for clarity.

FEDERAL AVIATION ADMINISTRATION

MASTER MINIMUM EQUIPMENT LIST

Page: VII Revision: 3 Date: 10/02/89

B-707 AND B-720

Definitions (Effective 10/2/89)

1. System Definitions.

System numbers are based on the Air Transport Association (ATA) Specification Number 100 and items are numbered sequentially.

- a. "Item" (Column 1) means the equipment, system, component, or function listed in the "Item" column.
- b. "Number Installed" (Column 2) is the number (quantity) of items normally installed in the aircraft. This number represents the aircraft configuration considered in developing this MMEL. Should the number be a variable (e.g., passenger cabin items) a number is not required.

NOTE: Where the MMEL shows a variable number installed, the MEL must reflect the actual number installed or an alternate means of configuration control approved by the Administrator.

c. "Number Required for Dispatch" (Column 3) is the minimum number (quantity) of items required for operation provided the conditions specified in Column 4 are met.

NOTE: Where the MMEL shows a variable number required for dispatch, the MEL must reflect the actual number required for dispatch or an alternate means of configuration control approved by the Administrator.

- d. "Remarks or Exceptions" (Column 4) in this column includes a statement either prohibiting or permitting operation with a specific number of items inoperative, provisos (conditions and limitations) for such operation, and appropriate notes.
- e. A vertical bar (change bar) in the margin indicates a change, addition or deletion in the adjacent text for the current revision of that page only. The change bar is dropped at the next revision of that page.

2. "Airplane/Rotorcraft Flight Manual" (AFM/RFM) is the document required for type certification and approved by the responsible FAA Aircraft Certification Office. The FAA approved AFM/RFM for the specific aircraft is listed on the applicable Type Certificate Data Sheet.

Page: VIII Revision: 3 Date: 10/02/89

MASTER MINIMUM EQUIPMENT LIST

B-707 AND B-720

Definitions (Effective 10/2/89)

3. "As required by FAR" means that the listed item is subject to certain provisions (restrictive or permissive) expressed in the Federal Aviation Regulations operating rules. The number of items required by the FAR must be operative. Items installed that are in excess of the FAR requirements may be permitted by the operator's MEL to be inoperative if not otherwise required by the MMEL.

4. "*" symbol in Column 4 indicates the listed item if inoperative, must be placarded to inform and remind the crewmembers and maintenance personnel of the equipment condition.

NOTE: To the extent practical, placards should be located adjacent to the control or indicator for the item affected; however, unless otherwise specified, placard wording and location will be determined by the operator.

5. "-" symbol in Column 2 and/or Column 3 indicates a variable number (quantity) of the item installed.

NOTE: Where the MMEL shows a variable number installed, the MEL must reflect the actual number installed or an alternate means of configuration control approved by the Administrator.

6. "Deleted" in the remarks column after a sequence item indicates that the item was previously listed but is now required to be operative if installed in the aircraft.

7. "ER" refers to extended range operations of a two-engine airplane which has a type design approval for ER operations and complies with the provisions of Advisory Circular 120-42A.

Page: IX Revision: 3 Date: 10/02/89

MASTER MINIMUM EQUIPMENT LIST

B-707 AND B-720

Definitions (Effective 10/2/89)

8. "Federal Aviation Regulations" (FAR) means the applicable portions of the Federal Aviation Act and Federal Aviation Regulations.

9. "Flight Day" means a 24 hour period (from midnight to midnight) either Universal Coordinated Time (UCT) or local time, as established by the operator, during which at least one flight is initiated for the affected aircraft.

10. "Icing Conditions" means an atmospheric environment that may cause ice to form on the aircraft or in the engine(s).

11. Alphabetical symbol in Column 4 indicates a proviso (condition or limitation) that must be complied with for operation with the listed item inoperative.

12. "Inoperative" means a system and/or component malfunction to the extent that it does not accomplish its intended purpose and/or is not consistently functioning normally within its approved operating limit(s) or tolerance(s).

13. "Notes:" in Column 4 provides additional information for crewmember or maintenance consideration. Notes are used to identify applicable material which is intended to assist with compliance, but do not relieve the operator of the responsibility for compliance with all applicable requirements. Notes are not a part of the provisos.

14. Inoperative components of an inoperative system: Inoperative items which are components of a system which is inoperative are usually considered components directly associated with and having no other function than to support that system. (Warning/caution systems associated with the inoperative system must be operative unless relief is specifically authorized per the MMEL).

MASTER MINIMUM EQUIPMENT LIST

Page: X Revision: 3 Date: 10/02/89

B-707 AND B-720

Definitions (Effective 10/2/89)

15. "(M)" symbol indicates a requirement for a specific maintenance procedure which must be accomplished prior to operation with the listed item inoperative. Normally these procedures are accomplished by maintenance personnel; however, other personnel may be qualified and authorized to perform certain functions. Procedures requiring specialized knowledge or skill, or requiring the use of tools or test equipment should be accomplished by maintenance personnel. The satisfactory accomplishment of all maintenance procedures, regardless of who performs them, is the responsibility of the operator. Appropriate procedures are required to be published as part of the operator's manual or MEL.

16. "(O)" symbol indicates a requirement for a specific operations procedure which must be accomplished in planning for and/or operating with the listed item inoperative. Normally these procedures are accomplished by the flight crew; however, other personnel may be qualified and authorized to perform certain functions. The satisfactory accomplishment of all procedures, regardless of who performs them, is the responsibility of the operator. Appropriate procedures are required to be published as a part of the operator's manual or MEL.

NOTE: The (M) and (O) symbols are required in the operator's MEL unless otherwise authorized by the Administrator.

17. "Deactivated" and "Secured" means that the specified component must be put into an acceptable condition for safe flight. An acceptable method of securing or deactivating will be established by the operator.

18. "Visual Flight Rules" (VFR) is as defined in FAR Part 91. This precludes a pilot from filing an Instrument Flight Rules (IFR) flight plan.

19. "Visual Meteorological Conditions" (VMC) means the atmospheric environment is such that would allow a flight to proceed under the visual flight rules applicable to the flight. This does not preclude operating under Instrument Flight Rules.

Page: XI Revision: 3 Date: 10/02/89

MASTER MINIMUM EQUIPMENT LIST

B-707 AND B-720

Definitions (Effective 10/2/89)

20. "Visible Moisture" means an atmospheric environment containing water in any form that can be seen in natural or artificial light; for example, clouds, fog, rain, sleet, hail, or snow.

21. "Passenger Convenience Items" means those items related to passenger convenience, comfort or entertainment such as, but not limited to, galley equipment, movie equipment, ash trays, stereo equipment, overhead reading lamps, etc.

22. Repair Intervals: All users of an MEL approved under FAR 121, 125, 129 and 135 must effect repairs of inoperative systems or components, deferred in accordance with the MEL, at or prior to the repair times established by the following letter designators:

Category A. Items in this category shall be repaired within the time interval specified in the remarks column of the operator's approved MEL.

Category B. Items in this category shall be repaired within three (3) consecutive calendar days (72 hours), excluding the day the malfunction was recorded in the aircraft maintenance record/logbook. For example, if it were recorded at 10 a.m. on January 26th, the three day interval would begin at midnight the 26th and end at midnight the 29th.

Category C. Items in this category shall be repaired within ten (10) consecutive calendar days (240 hours), excluding the day the malfunction was recorded in the aircraft maintenance record/logbook. For example, if it were recorded at 10 a.m. on January 26th, the 10 day interval would begin at midnight the 26th and end at midnight February 5th.

The letter designators are inserted adjacent to Column 2.

23. Engine Indicating Crew Alerting System (EICAS), Electronic Centralized Aircraft Monitoring System (ECAM) or similar systems that provide electronic messages refer to a system capable of providing different priority levels of systems information messages (e.g., Warning, Caution, Advisory Status and Maintenance). Any airplane discrepancy message that affects dispatchability will normally be at status message level (e.g., Advisory Status) or higher.

Page: XII Revision: 3 Date: 10/02/89

MASTER MINIMUM EQUIPMENT LIST

B-707 AND B-720

Definitions (Effective 10/02/89)

24. "Administrative control item" means an item listed by the operator in the MEL for tracking and informational purposes. It may be added to an operator's MEL by approval of the Principal Operations Inspector provided no relief is granted, or provided conditions and limitations are contained in an approved document (i.e. Structural Repair Manual, airworthiness directive, etc.). If relief other than that granted by an approved document is sought for an administrative control item, a request must be submitted to the Administrator. If the request results in review and approval by the FOEB, the item becomes an MMEL item rather than an administrative control item.

25. "***" symbol in Column 1 indicates an item which is not required by regulation but which may have been installed on some models of aircraft covered by this MMEL. This item may be included on the operator's MEL after the approving office has determined that the item is installed on one or more of the operator's aircraft. The symbol, however, shall not be carried forward into the operator's MEL. It should be noted that neither this definition nor the use of this symbol provide authority to install or remove an item from an aircraft. B-707 AND B-720

Preamble (Effective 6/14/89)

The following is applicable for authorized certificate holders operating under Federal Aviation Regulations (FAR) Parts 121, 125, 129, 135: The FAR require that all equipment installed on an aircraft in compliance with the Airworthiness Standards and the Operating Rules must be operative. However, the Rules also permit the publication of a Minimum Equipment List (MEL) where compliance with certain equipment requirements is not necessary in the interests of safety under all operating conditions. Experience has shown that with the various levels of redundancy designed into aircraft, operation of every system or installed component may not be necessary when the remaining operative equipment can provide an acceptable level of safety. A Master Minimum Equipment List (MMEL) is developed by the FAA, with participation by the aviation industry, to improve aircraft utilization and thereby provide more convenient and economic air transportation for the public. The FAA approved MMEL includes those items of equipment related to airworthiness and operating regulations and other items of equipment which the Administrator finds may be inoperative and yet maintain an acceptable level of safety by appropriate conditions and limitations; it does not contain obviously required items such as wings, flaps, and rudders. The MMEL is the basis for development of individual operator MELs which take into consideration the operator's particular aircraft equipment configuration and operational conditions. Operator MELs, for administrative control, may include items not contained in the MMEL; however, relief for administrative control items must be approved by the Administrator. An operator's MEL may differ in format from the MMEL, but cannot be less restrictive than the MMEL. The individual operator's MEL, when approved and authorized, permits operation of the aircraft with inoperative equipment.

Equipment not required by the operation being conducted and equipment in excess of FAR requirements are included in the MEL with appropriate conditions and limitations. The MEL must not deviate from the Aircraft Flight Manual Limitations, Emergency Procedures or with Airworthiness Directives. It is important to remember that all equipment related to the airworthiness and the operating regulations of the aircraft not listed on the MMEL must be operative. B-707 AND B-720

Preamble (Effective 6/14/89)

Suitable conditions and limitations in the form of placards, maintenance procedures, crew operating procedures and other restrictions as necessary are specified in the MEL to ensure that an acceptable level of safety is maintained.

The MEL is intended to permit operation with inoperative items of equipment for a period of time until repairs can be accomplished. It is important that repairs be accomplished at the earliest opportunity. In order to maintain an acceptable level of safety and reliability the MMEL establishes limitations on the duration of and conditions for operation with inoperative equipment. The MEL provides for release of the aircraft for flight with inoperative equipment. When an item of equipment is discovered to be inoperative, it is reported by making an entry in the Aircraft Maintenance Record/Logbook as prescribed by FAR. The item is then either repaired or may be deferred per the MEL or other approved means acceptable to the Administrator prior to further operation. MEL conditions and limitations, do not relieve the operator from determining that the aircraft is in condition for safe operation with items of equipment inoperative.

When these requirements are met, an Airworthiness Release, Aircraft Maintenance Record/Logbook entry, or other approved documentation is issued as prescribed by FAR. Such documentation is required prior to operation with any item of equipment inoperative.

Operators are responsible for exercising the necessary operational control to ensure that an acceptable level of safety is maintained. When operating with multiple inoperative items, the interrelationships between those items and the effect on aircraft operation and crew workload will be considered.

Operators are to establish a controlled and sound repair program including the parts, personnel, facilities, procedures, and schedules to ensure timely repair.

WHEN USING THE MEL, COMPLIANCE WITH THE STATED INTENT OF THE PREAMBLE, DEFINITIONS, AND THE CONDITIONS AND LIMITATIONS SPECIFIED IN THE MEL IS REQUIRED.

FEC	ERAL AVIATION ADM	IINISTRA	ATION	ſ	MASTER MINIMUM EQUIP	PMENT LIST				
	CRAFT:				REVISION NO: 37	 PAGE:				
	B-707 AN	ID B-72	0		DATE: 10/19/90	21-1				
		1.	2.	NUMBE	R INSTALLED	·				
SEÇ	SYSTEM & SEQUENCE ITEM		ļ	3. NUMBER REQUIRED FOR DISPATCH						
NUM 	BERS				4. REMARKS OR EXCEPTIONS					
21	AIR CONDITIONING	1								
1.	Turbocompressors and Engine Bleed		 							
	1) B-707 Turbo- compressors	С	– 	0	<pre>*May be inoperative provi bleeds operate normally.</pre>	ided three				
		С	 - 	1	<pre>*Two may be inoperative r two bleeds operate normal</pre>					
		С	-	2	 *					
					NOTE: Use of turbocompres bleed on same engin permitted.					
	2) B-720 Turbo- Compressors	С	 2 	0	<pre>*May be inoperative provi bleeds operate normally.</pre>	ided three				
		С	 2 	1	<pre>*One may be inoperative r two bleeds operate normal</pre>					
					NOTE: Use of turbocompres bleed on same engine is r permitted.					
	3) B-707/720 Engine Bleeds	C	4	0	<pre>*May be inoperative provi turbocompressors operate</pre>					
		С	4	3	*					
		С	4 	2	<pre>*Two may be inoperative p one turbocompressor opera normally.</pre>					
		С	4	1	<pre>*Three may be inoperative two turbocompressors oper normally.</pre>					
			 		 NOTE: Use of turbocompres bleed on same engin permitted.					

FED	ERAL AVIATION ADMINIS	STR <i>i</i>	ATION		MASTER MINIMUM EQUIPMEN	r list
AIR	CRAFT:				REVISION NO: 37	PAGE:
	B-707 AND B-	-720)		DATE: 10/19/90	21-2
		.	2.1	NUMBEI	R INSTALLED	
SEQ	TEM & UENCE ITEM BERS			3.1 .	NUMBER REQUIRED FOR DISPATCH	
 21	AIR CONDITIONING				4. REMARKS OR EXCEPTIONS	
2.	Turbocompressor Shut-Off Valves	С	-	0	*May be inoperative for any inoperative turbocompressor.	
3.	Turbocompressor Bearing Temperature Warning Systems	C	_	 0 	*	
4.	Turbocompressor Low Oil Pressure Warning Systems	С	-	0 	*May be inoperative on one op ting turbocompressor provided associated tachometer and Ove Warning system operate normal	d erspeed
5.	Turbocompressor Overspeed Warning	C	_	0 	*May be inoperative on one of ting turbocompressor provided associated tachometer and Low Pressure Warning system opera normally.	d v Oil
6.	Turbocompressor Tachometer	С	_	0 	*May be inoperative on one of ting turbocompressor provided associated Low Oil Pressure W and Overspeed Warning system operate normally.	ł
7.	Bleed Shut-Off Valve	С	4	0	*May be inoperative for an in tive air bleed source.	nopera-
8.	Turbocompressor Pressure Regulating Valves	С	-	 0 	*May be inoperative for an in tive turbocompressor.	nopera-

U.S. DEPARTMENT OF TRAN	ISPOF	RTATI	ON	
FEDERAL AVIATION ADMINI	STR	ATION		MASTER MINIMUM EQUIPMENT LIST
AIRCRAFT:				REVISION NO: 37 PAGE:
B-707 AND E	8-720)		DATE: 10/19/90 21-3
	1.	2.1	NUMBEI	R INSTALLED
SYSTEM & SEQUENCE ITEM NUMBERS		-	3.1 -	NUMBER REQUIRED FOR DISPATCH
21 AIR CONDITIONING				4. REMARKS OR EXCEPTIONS
9. Ram Air Shut-Off Valves	С	2	1	*One may be inoperative closed provided circuit breaker is pulled and collared.
	С	2	0	*May be inoperative closed provided two packs operate normally.
	С	2	0	*May be inoperative provided flight is conducted in an unpressurized configuration.
10. Air Conditioning Packs	С	2	 1 	*One may be inoperative provided associated pack shut-off valve remains closed.
	С	2	 0 	*May be inoperative provided flight is conducted in an unpressurized configuration.
11. Flight Deck Airflow Controller	С	1	0	*
12. Pack Coolant System (Inlet, 2 Exit and Heat Exchange Doors				
1) Air Cycle	С	2	0	*(M)Doors may be inoperative deactivated and secured fully open.
2) Vapor Cycle	С	1	0	*(M)Auxiliary Air Inlet Door may be inoperative deactivated and secured in any position.
a) Primary Heat Exchanger Door	С	1	0	*(M)May be inoperative deactivated and secured fully open.
			 	(Continued)

FEDERAL AVIATION ADMINIST	RATION	ī	MASTER MINIMUM EQUIP	MENT LIST
AIRCRAFT:			REVISION NO: 37	 PAGE:
B-707 AND B-7	20		 DATE: 10/19/90	21-4
1.	2.	NUMBEI	R INSTALLED	
SYSTEM & SEQUENCE ITEM NUMBERS		3.1	NUMBER REQUIRED FOR DISPATC	 H
21 AIR CONDITIONING		ļ	4. REMARKS OR EXCEPTIONS	
12. Pack Coolant System (Inlet, 2 Exit and Heat Exchange Doors) (Cont'd)				
b) Ram Air C Inlet Door	1	0	<pre>*(M)May be inoperative de and secured fully open.</pre>	activated
С	1	0	*(M)May be inoperative de in AUTO-OPEN (60% OPEN) p freon compressor remains outside air temperatures degrees C.	rovided OFF at
c) Condenser C Fan Exit Door	1	0	 *(M)May be inoperative de in 35% open to fully open	
13. Pack Cooling Door Indicators				
1) Air Cycle				
a) Ram Air C Inlet and Exit Indications	2	0	 *May be inoperative provi associated door(s) remain open. 	
b) Turbofan C Exit Indication		0	* *	
c) Secondary C Heat Exchanger Indication	1 	0	<pre> *(M)May be inoperative pr associated door is deacti secured fully open.</pre>	
			(Continued)	

FEDERAL AVIATION ADMINIST	ATION	ſ	MASTER MINIMUM EQUI	IPMENT LIST
AIRCRAFT:			REVISION NO: 37	PAGE:
B-707 AND B-72	0		 DATE: 10/19/90	21-5
			 R INSTALLED	
SYSTEM & SEQUENCE ITEM NUMBERS	i		NUMBER REQUIRED FOR DISPAT	
21 AIR CONDITIONING			4. REMARKS OR EXCEPTIONS	5
 Pack Cooling Door Indicators (Cont'd) 				
2) Vapor Cycle	İ			
a) Ram Air C Inlet, Primary Exchanger and Condenser Fan Exit Indicators			*May be inoperative prov a) Associated door i fully open with a pack OFF before a departure, and b) Cooling Door cont not used in fligh	s verified associated each crols are
b) Auxiliary C Air Inlet Door Indication	1	0	*	
14. Gasper Fan C	1	0	 *	
5. Programmer Bypass C Controls	1	0	 * 	
16. Cabin Pressure Control				
1) Automatic C	1	0	 *May be inoperative prov system operates normally	
2) Manual (Elec- C tric or Pneumatic)			*May be inoperative prov a) Flight is conduct unpressurized cor and b) Only non-combusti materials are car lower cargo compa	ed in an figuration, ble cried in the
17. Cabin Airflow C Indicator	1	 0 	 * 	

FEDERAL	AVIATION ADMINI	STR	ATION		MASTER MINIMU	M EQUIPMENT LIST
AIRCRAF	 ?T:				REVISION NO:	37 PAGE:
	B-707 AND B	-720	 DATE: 10/19/9	0 21-6		
		1.	2.1		INSTALLED	
SYSTEM & SEQUENCE ITEM		.		IUMBER REQUIRED FOR		
	MBERS			.	4. REMARKS OR EXCE	PTIONS
18. Cab	R CONDITIONING bin Altitude dicator	С	1	0 	Indicator o and b) A chart is flight crew	rential Pressure perates normally, provided for the to convert cabin l pressure to
		С				onducted in an ed configuration.
	din Differential essure Indicator	С		0 	b) A chart is flight crew	-
		С			c) Flight is c	onducted in an ed configuration.
	oin Rate of Imb Indicator	С	1	0	tion system normally. OR b) Flight is c	omponents and f the pressuriza-
	oin Altitude rning System	С	1 	 0 	*May be inoperativ flight remains at feet MSL.	

FEDERAL AVIATIO	N ADMINI	STRA	ATION		MASTER MINIMUM	EQUIPMENT LIST	
AIRCRAFT:					REVISION NO: 3	7 PAGE:	
B-7	07 AND B	-720)	 DATE: 10/19/90	 21-7		
				NUMBE	R INSTALLED		
SYSTEM & SEQUENCE ITEM NUMBERS					NUMBER REQUIRED FOR D		
21 AIR CONDITIO		İ		4. REMARKS OR EXCEPTIONS			
22. Air Conditioning Outflow Valves		C 	2	1 	*(M)(O)One may be in provided: a) Valve is dead and b) Both automat: controls open the remaining	ctivated closed, ic and manual cate normally on	
		C	2		 b) Extended over prohibited, a c) Only non-comb materials are lower cargo of 	nducted in an d configuration, cwater flight is and pustible e carried in the	
		с			OR d) Compartment 1	remains empty.	
23. Thrust Reco Valves	very	C	3	0	*May be inoperative	closed.	
24. Cabin Heate:	r	C	1	0	*		
25. Flight Deck	Heater	с	1	0	*		
26. Cold Air Pro Regulator	essure	C 	1	0	*(M)May be inoperat: spring loaded flappe located downstream o normally.	er valves	
27. Condenser Fa Override Ci		C	1	0	 * 		
28. Zone Tempera Control Val		C	3	0	*May be inoperative	closed.	
					(Continued)		

EDERAL AVIATION ADMIN	NISTR <i>i</i>	ATION		MASTER MINIMUM EQUIPMENT LIST
IRCRAFT:				REVISION NO: 37 PAGE:
B-707 AND	B-720)		DATE: 10/19/90 21-8
	1.	2.1	NUMBEI	R INSTALLED
YSTEM & EQUENCE ITEN IUMBERS	1		 3.1 -	NUMBER REQUIRED FOR DISPATCH
1 AIR CONDITIONING				4. REMARKS OR EXCEPTIONS
8. Zone Temperature Control Valves (Cont'd)	С	3	0	<pre>*(M)May be inoperative partially open to fully open provided a blocking plate is installed to prevent airflow.</pre>
9. Temperature Indicators (Air & Freon)		2	0	*Evaporator discharge air or freon temperature indicator function may be inoperative for both freon packs.
	С	2	0	*Air and freon temperature indi- cators may be inoperative provided automatic temperature control system operates normally.
	С	2	0	*All temperature indications for an inoperative pack may be inoperative.
0. Equipment Cooling Exhaust Blower Mot	or			Deleted, Rev. 37
1. Equipment Cooling Exhaust Valve				
1) Automatic Function	С	1	 0 	<pre>*May be inoperative provided mechanical manual or electrical manual control and indicator operate normally.</pre>
2) Valve Indicator	c C	1	 0 	<pre>*(M)May be inoperative provided: a) Motorized valve is verified to operate normally with control switch. OR b) Non-motorized valve is positioned manually, and c) NO AIRFLOW warning light</pre>

FEDERAL AVIATION ADMINISTRA	ATION		MASTER MINIMUM EQUIP	MENT LIST
AIRCRAFT:			REVISION NO: 37	 PAGE:
B-707 AND B-720	C		 DATE: 10/19/90	 21-9
	2.1	NUMBEI	R INSTALLED	
SYSTEM & SEQUENCE ITEM NUMBERS	. 	 3.1 -	NUMBER REQUIRED FOR DISPATC	 H
21 AIR CONDITIONING			4. REMARKS OR EXCEPTIONS	
32. Equipment Cooling Exhaust Valve Indicator			Deleted, Rev. 37	
33. Flight Deck Temper- ature Control				
1) All Except C B-707-300C	 1 	 0 	*May be inoperative provi- matic, manual or programm control operates normally	er bypass
2) B-707-300C Only C	1	0 	*(M)May be inoperative pr a) Cabin Temperature Valve is deactivat COLD, and b) Crew Auxiliary Hea operates normally.	Control ed fully
34. Flight Deck Temper- ature Manual Shutoff Control Valve			Deleted, Rev. 37	
35. Main Cabin Temperature Control Manual (Electrical)		 		
1) Air Cycle C	 1 	 0 	*May be inoperative provi (Mechanical) Override ope normally.	
2) Vapor Cycle C	1	0 	*May be inoperative provi- a) Manual (Mechanical operates normally, b) Programmer Bypass operates normally. OR) Override and Control
C	 	 	c) Electrical Overrid normally.	e operates

FEDERAL AVIATION ADMINI	STR	ATION		MASTER MINIMUM EQUIPM	MENT LIST
AIRCRAFT:				REVISION NO: 37	PAGE:
B-707 AND B	-72	C		 DATE: 10/19/90	21-10
	 1.	2.1	NUMBE	R INSTALLED	
SYSTEM & SEQUENCE ITEM NUMBERS		. 	3.1	NUMBER REQUIRED FOR DISPATCH	 H
21 AIR CONDITIONING				4. REMARKS OR EXCEPTIONS	
36. Main Cabin Tempera- ture Control (Automatic)					
1) Air Cycle	С	1	0	<pre>*May be inoperative provid (Mechanical) Override oper normally.</pre>	
2) Vapor Cycle	С	1 	 	<pre>*May be inoperative provid a) Manual (Mechanical) operates normally, b) Programmer Bypass (operates normally. OR</pre>) Override and
	С			c) Electrical Override	e operates
37. Main Cabin Tempera- ture Control Manual (Mechanical or Electrical) Overrid		1	 0 	* 	
38. Cabin Temperature Indicator	С	1	0	 * 	
39. Water Separator Ice Control	С		 1 	 *One may be inoperative fo associated inoperative page	
	С	2	0	 *May be inoperative for as inoperative air condition	

FEDERAL AVIATION	ADMINISTR	ATION		MASTER MINIMUM EQUIP	MENT LIST
AIRCRAFT:				REVISION NO: 37	PAGE:
B-70	7 AND B-72	0		 DATE: 10/19/90	 21-11
	1.	2.	NUMBE	R INSTALLED	
SYSTEM & SEQUENCE JUMBERS	ITEM		3.]	NUMBER REQUIRED FOR DISPATC	
21 AIR CONDITIO	NING			4. REMARKS OR EXCEPTIONS	
10. Recirculation (Vapor Cycle		-	0	* *	
1. Pack Shut-Of: Valves	E C	2	1	*May be inoperative for a inoperative pack. 	ssociated
42. Air Condition Ground Connec Check Valve	-		0	 *May be inoperative close 	d.
	C		0	*May be inoperative open flight is conducted in an unpressurized configurati	_ L
13. Override Sys	tem			Deleted, Rev. 37	
44. Pack Turbofa	n C	2	0	<pre>*May be inoperative provi associated pack is not op the ground.</pre>	
45. Pack Trip Wa: System	rning C	2	0	<pre> *May be inoperative for i pack(s).</pre>	noperative
46. Pack Turbofan Shut-Off Valv	-	2	0	<pre>*May be inoperative close associated pack is not op the ground.</pre>	-
47. Duct Overheat Warning Light		2	1 	 *Main Cabin Light may be inoperative provided cabi air temperature indicator normally. 	
				1	

FED	ERAL AVIATI	ON ADMINI	STRA	ATION		MAS	TER MINIMUM EQU	IPMENT LIST
AIR	CRAFT:					 REV	ISION NO: 37	PAGE:
	B-	707 AND B	-720)		 DAT	E: 10/19/90	22-1
		·	1.	2.1	NUMBEI	INSTALLE	 D	
SEQ	YSTEM & EQUENCE ITEM UMBERS				3.1 -	UMBER REQ	UIRED FOR DISPA	 ТСН
		 HT				4. REMAR	KS OR EXCEPTION	S
	Autopilot	System	C	-	0		inoperative pro minimums do no	
							y mode which fu rmally may be u	
	1) Control Disenga	Wheel ge Switch		2	1		be inoperative t is not used b	
2.	Yaw Damper		C	2	0		be inoperative ons are observe	
3.	Comparator	Unit	С	1	0	*		
	Mach Trim	System	C	1	 		be inoperative tations are obs	
					ļ			

FEDERAL AVI	ATION ADMIN	ISTRA	ATION		MASTER MIN	IIMUM EQUI	PMENT LIST
AIRCRAFT:					REVISION N	10:37	PAGE:
	B-707 AND 1	3-720)		 DATE: 10/1	9/90	23-1
		1.	2.	NUMBE	R INSTALLED		
SYSTEM & SEQUENCE NUMBERS	ITEM			3. 1 	NUMBER REQUIRED F	OR DISPAT	'СН
23 COMMUNI	CATIONS				4. REMARKS OR E 	XCEPTIONS	
	ve Call (SELCAL)	C	1	0	 * 		
2. Communi Systems UHF)	cation (HF, VHF,	С	_	 - 	*(0)As required 	l by FAR.	
System to Cabi Flight	Interphone Flight Deck n/Cabin to Deck/Flight Ground		1	 0 	establis	e, normal y procedu shed and u	., and tres are
					NOTE: Not requi operation		ll-cargo
	ttendant's one System	C	1	0	establis	e, normal y procedu shed and u	., and tres are
					NOTE: Not requi operation		ll-cargo
5. Flight Speaker		С	2	 0 	*May be inopera a) Procedur their us b) Headsets operate	res do not se, and	require
6. Passeng System	er Address	A	1	0 			., and tres are
				 	 (Continued)		

FED	ERAL AVIATION ADMINIS	TRATION	1	MASTER MINIMUM EQUIPM	ENT LIST
AIR	 CRAFT:			REVISION NO: 38	 PAGE:
	B-707 AND B-	720		 DATE: 11/14/90	23-2
 va		2.	NUMBE	R INSTALLED	
ΕQ	TEM & UENCE ITEM BERS		3. 1	NUMBER REQUIRED FOR DISPATCH	
	COMMUNICATIONS	-		4. REMARKS OR EXCEPTIONS 	
•	Passenger Address System (Cont'd)			<pre>b) Flight Deck-Cabin/In function (two-way) of normally, and c) The airplane may con the flight or series flights for a maximu flight hours (Domest 25 flight hours (Int national). NOTE: Not required for all- operations.</pre>	operates ntinue s of um of 15 tic) or ter-
	Flight Deck Interphone System			Deleted, Rev. 37	
-	Audio Selector o Panels	2 -	4	<pre>*Any in excess of those red for flight deck crewmembers (including official observe forward observer's seat) ma inoperative.</pre>	er in
•	Cockpit Voice 2 Recorder (CVR) System	A 1	0	*May be inoperative provide a) Flight Data Recorder operates normally, a b) Repairs are made wit three flight days.	r (FDR) and
0.	H.F. Communications Transmitters and Receivers			Deleted, Rev. 37	

FED	ERAL AVIATION ADMINI	STR	ATION	ī	MASTER MINIMUM EQUIPN	MENT LIST			
AIR	CRAFT:				REVISION NO: 37	PAGE:			
	B-707 AND E				 DATE: 10/19/90	24-1			
				NUMBEI	R INSTALLED				
SEQ	TEM & UENCE ITEM BERS				3. NUMBER REQUIRED FOR DISPATCH				
 24	ELECTRICAL POWER				4. REMARKS OR EXCEPTIONS				
1.	Generator Systems	В	4	3	*One may be inoperative pr AC Buses are paralleled.	rovided			
2.	CSD Low Pressure Lights	C	4	0	*May be inoperative provid associated generator funct indicators operate normall	ions and			
3.	CSD Oil Temper- ature Indicator	С	4	0	*May be inoperative provid a) Associated KW/KVAR Loadmeter operates and b) CSD low pressure li operate normally.	Meter or normally,			
4.	Generator Overheat Lights	С	4	0	*				
5.	Frequency Meter				Deleted, Rev. 37				
6.	KW/KVAR Meter (Or Loadmeter)	С		2 	*Two KW/KVAR Meters or Loa may be inoperative provide associated CSD oil tempera indicators operate normal NOTE: KVAR function may be tive on all meters.	ed ature Ly.			
7.	A.C. Voltmeter			 	Deleted, Rev. 37				
8.	D.C. Meter Indications								
	1) VOLTS	С	4	0	*May be inoperative for ar provided associated AMPS i operates normally. (Continued)	-			

FEDER	AL AVIATION ADMIN	ISTR <i>i</i>	ATION		MASTER MINIMUM EQU	IPMENT LIST
AIRCR	AFT:				REVISION NO: 37	 PAGE:
	B-707 AND 1	3-72()		 DATE: 10/19/90	24-2
		1.	2.		R INSTALLED	
SYSTE SEQUE NUMBE	ITEM ITEM				NUMBER REQUIRED FOR DISPA	
 24 е	LECTRICAL POWER			ĺ	4. REMARKS OR EXCEPTION 	S
	O.C. Meter Indications (Cont'o	1)				
2) AMPS	С	4	3 	*May be inoperative for provided: a) Associated VOLTS operates normall b) Remaining T.R.'s cations operate	indication y, and AMPS indi-
Э. Е	attery System				 Deleted, Rev. 37	
	ransformer ectifiers (T.R.)	С	4	 3 	*No. 3 or No. 4 T.R. ma inoperative provided: a) All D.C. Buses o normally, and b) No. 2 and Essent operate normally	perate ial T.R.
	xternal Power System	С	1	0	* *	
a	utomatic Gener- tor Paralleling System	С	1	0	*(O)May be inoperative a) Manual paralleli operate normally b) Manual paralleli cedures are used	ng functions , and ng pro-
	enerator ynchronize Lights	С		0 	*(0)May be inoperative a) Auto paralleling operate normally b) Manual paralleli cedures are not	functions , and ng pro-

FEDERAL AVIATION ADMINISTRA	ATION		MASTER MINIMUM EQU	IPMENT LIST
AIRCRAFT:			REVISION NO: 37	 PAGE:
B-707 AND B-720)		DATE: 10/19/90	24-3
1.	2. NUI	 MBER INSI	 TALLED	
SYSTEM & SEQUENCE ITEM NUMBERS		3. NUMBEF	REQUIRED FOR DISPA	
24 ELECTRICAL POWER		4. F 	REMARKS OR EXCEPTION	5
l4. Essential Power Selector				
1) Generator C Positions	4	prov 	 e may be inoperative vided: a) Essential power of normally from repositions, b) Remaining AC gene operate normally c) AC Buses are para d) Circuit breaker(sinoperative positipulled and collar) 	maining erators , alleled, and s) for the tion is

FED	ERAL AVIAT	ION ADMIN	NISTRA	ATION			MASTER MINIMUM EQU	IPMENT LIST			
 AIR	CRAFT:						REVISION NO: 38	PAGE:			
	B·	-707 AND						25-1			
							TALLED				
SEQ	SYSTEM & SEQUENCE ITEM JUMBERS				3. 1		REQUIRED FOR DISPA				
	EQUIPMENT	/FURNISHI	INGS	 		4. REMARKS OR EXCEPTIONS					
1.	Megaphone	5	С	 – 	2		v in excess of those may be inoperative.				
						 NOTE 	: Not required for operations.	all-cargo			
2.	Crewmembe: Shoulder 1 (Flight De	Harness	С	_ 	4	for offi	y in excess of those flight crewmembers ccial observer in for yer's seat) may be in	(including rward ob-			
3.	Flight At Seat Asser (Single or Position)	nbly	С			posi prov 	One seat or assembly tion) May be inoper- vided: a) Affected seat or assembly is not b) Flight attendant placed by inoper- seat(s) occupies ger seat most ac his or her assign ntinued)	ative seat occupied, (s) dis- ative the passen- cessible to			

FEDERAL AVIATION ADMINISTRAT	MASTER MINIMUM EQUIPM	IENT LIST
AIRCRAFT:	REVISION NO: 37	PAGE:
B-707 AND B-720	DATE: 10/19/90	 25-2
	2. NUMBER INSTALLED	
SYSTEM & SEQUENCE ITEM NUMBERS	3. NUMBER REQUIRED FOR DISPATCH	
25 EQUIPMENT/FURNISHINGS	4. REMARKS OR EXCEPTIONS	
3. Flight Attendant Seat Assembly (Single or Dual Position) (Cont'd)	<pre>c) Alternate procedure established for dis flight attendant(s) d) Folding type seat i or secured in the r position, and e) Passenger seat(s) a to flight attendant placarded "FOR FLIG ATTENDANT USE ONLY" NOTE 1: A folding seat tha not stow automatic considered inopera NOTE 2: A seat position wi sing or inoperativ belt and/or should harness is conside inoperative. NOTE 3: The above provisos only to required f attendant seats. S</pre>	<pre>splaced , .s stowed retracted assigned (s) is HT</pre>
		eat posi- those operative properly in the . Indi-
	operating with inc operating with inc seats, will consid locations and comb of seats to assure proximity to exits tribution requirem the applicable FAR	perative ler the pinations that the and dis- ments of

FEI	DERAL AVIATI	ION ADMINI	STRA	ATION			MASTER MINIMUM EQUI	PMENT LIST
AIF	CRAFT:				REVISION NO: 37	PAGE:		
	B-	-707 AND E	8-720)		DATE: 10/19/90 25-		 25-3
			1.	2.1	NUMBEI		'ALLED	
SYSTEM & SEQUENCE ITEM NUMBERS			3.1		MBER REQUIRED FOR DISPATCH			
 25	EQUIPMENT	FURNISHIN	 IGS			4. F 	REMARKS OR EXCEPTIONS	
4.	Flight Att Flashlight Assemblies	Holder	C 	-		 *May be inoperative or missing provided the crewmember assigned associated seat has a flashlight equivalent characteristics readi available. 		assigned to ashlight of
5.	"Fasten Se While Seat or Placarc	ed" Signs	-	-	 - 	<pre>*One or more signs or placards ma be illegible or missing provided legible sign or placard is readab from each occupied passenger seat</pre>		provided a is readable
6.	Passenger	Seats						
	1) Seat Ba	acks	C	-	-		May be inoperative s upright position.	ecured in
			C	-		thar prov NOTE	May be inoperative in the upright position vided: a) Does not block an Exit, b) Does not restrict senger from access main aircraft ais c) The affected seat blocked and place Not Occupy". c 1: A seat with an i seat belt is con inoperative. c 2: Inoperative seat affect the requi of Flight Attendom seat belt is con flight attendom seat belt is con flight. 	n Emergency a Emergency a any pas- as to the ele, and (s) is arded "Do noperative sidered as do not red number

U.S. DEPARTMENT OF TRANSPOR	RTATI	ON				
FEDERAL AVIATION ADMINISTRA	ATION		MASTER MINIMUM EQUIPMENT LIST			
AIRCRAFT:			REVISION NO: 38 PAGE:			
B-707 AND B-720)		DATE: 11/14/90 25-4			
	2.1	NUMBEI	R INSTALLED			
SYSTEM & SEQUENCE ITEM NUMBERS		3. NUMBER REQUIRED FOR DISPATCH				
25 EQUIPMENT/FURNISHINGS			4. REMARKS OR EXCEPTIONS			
7. Emergency Locator C Transmitter (ELT)	-	-	*Any in excess of those required by FAR may be inoperative.			
8. Passenger Convenience Item(s)	_	0	<pre>*Passenger convenience items, as expressed in this MMEL, are those items related to passenger con- venience, comfort, or entertainment such as, but not limited to: galley equipment, movie equipment, ash trays, stereo equipment, overhead reading lamps, etc. Items addressed elsewhere in this document shall not be included. (M) and (O) pro- cedures may be required and included in the Air Carrier's appropriate document.</pre>			
9. First-Aid Kit C	-	 - 	items. *Any in excess of those required by FAR may be inoperative.			
10. PBE Smokehoods C	-	-	*Any in excess of those required by FAR may be inoperative.			
11. Forward Observer's A Seat	1	0 	 *May be inoperative provided: a) A passenger seat in the passenger cabin is made available to an FAA inspector for the performance of official duties, and b) Operators are limited to not more than two flight days before repairs are made. 			
1) Additional C Observer Seat(s)	-	0	*			

EDERAL AVIATIO	N ADMINISTR	ATION			MASTER MINIMUM EQUI	PMENT LIST		
IRCRAFT:					REVISION NO: 37	 PAGE:		
B-7	07 AND B-72	0			DATE: 10/19/90	 26-1		
	1.	2.1	NUMBEI	R INST	'ALLED			
YSTEM & EQUENCE IUMBERS	ITEM	 	3.1	3. NUMBER REQUIRED FOR DISPATCH				
6 FIRE PROTEC	TION			4. REMARKS OR EXCEPTIONS				
. Engine Fire Detection S Test Featur	ystem	 1 	 0 	alte	May be inoperative p ernate procedure is u fy system integrity.	sed to		
. Wheel Well Detection S	Fire C ystem		 0 	 	May be inoperative p a) A procedure is us verify that brake tures are not exc b) After takeoff, la remains extended minutes.	ed to tempera- essive, and nding gear		
				NOTE 	1: In case of an en ure after V1, pe is the prime con The landing gear retracted normal gear down perfor not a problem. consider the eff associated with raising or cycli ing gear during operations.	rformance sideration. should be ly until mance is Pilots must ects delayed ng of land-		
		l		Ì				

	. DEPARTMENT OF TRAN				MASTER MINIMUM EQUIPMENT LIST
FEDE	ERAL AVIATION ADMIN	ISTRA	ATION		
AIRC	CRAFT:				REVISION NO: 37 PAGE:
	B-707 AND B	3-720	C		DATE: 10/19/90 26-2
		1.	2.1	NUMBEI	2 INSTALLED
	FEM & JENCE ITEM BERS		-	3.1 -	IUMBER REQUIRED FOR DISPATCH
 26	FIRE PROTECTION				4. REMARKS OR EXCEPTIONS
3.	Engine Fire Extinguisher Discharge Light	С	_ 	0 	*(M)May be inoperative provided a test procedure is used once each flight day to verify that associ- ated bottle(s) is properly charged
4.	Engine Fire Extinguisher Therma Discharge Discs	C al/	4	 0 	*(M)May be missing provided gauge readings or other means are used to verify that associated bottle(s) is full.
5.	Firewall Shutoff Systems				Deleted, Rev. 37
6.	Engine Fire Extinguisher Syster	ns			Deleted, Rev. 37
7.	Portable Fire Extinguishers	С	_ 	 – 	*Any in excess of those required by FAR may be inoperative or missing provided required distribution is maintained throughout the aircraft
					NOTE: Any bottle not properly serviced is considered inoperative and should be removed.
8.	Aft Cargo Compartment Fire Warning Light	С	– 	0 	*May be inoperative provided only non-combustible materials are carried in associated compartment.
9.	Master Fire Warning Lights (Forward Glare Shield)	В	2		*One may be inoperative provided all other fire warning devices, both visual and aural, operate normally.

FED	ERAL AVIATION ADMIN	ISTR	ATION			MASTER MINIMUM EQUIPMEN	NT LIST			
	CRAFT:					REVISION NO: 37				
	B-707 AND 1	B-72	n			 DATE: 10/19/90	26-3			
						 FALLED				
	TEM &									
	UENCE ITEM BERS		ļ	3.	3. NUMBER REQUIRED FOR DISPATCH					
 26	FIRE PROTECTION				4. E 	4. REMARKS OR EXCEPTIONS				
10.	Forward Lower Cargo Compartment Class B Smoke Detection System			0 	*May 	 y be inoperative provided a) Compartment remains of and b) Heater remains OFF. OR c) Only non-combustible materials are carried associated compartment 	empty, d in			
11.	Main Cargo Smoke Detection System	C	 	 0 	*May 	y be inoperative provided a) Aircraft is operated passenger configurat: OR b) No cargo is carried o main deck.	d: in a ion.			
12.	Lavatory Fire Extinguisher	C			lava	 (O)May be inoperative for a long provided the associant a) Lavatory smoke detections system(s) operates not or or or or or or or or or or or or or	iated: tion prmally. tacle is ked , "INOP- ER", and for any hot e s by			

EDERAL AVIATION ADMINIS	TRATION	ī		MASTER MINIMUM EQU	IPMENT LIST				
AIRCRAFT:			 	REVISION NO: 37	 PAGE:				
B-707 AND B-	720			DATE: 10/19/90	26-4				
	. 2.	NUMBER INSTALLED							
SYSTEM & SEQUENCE ITEM IUMBERS		3.1	NUMBER	REQUIRED FOR DISPA'	 ТСН 				
6 FIRE PROTECTION	-		4. RE 	MARKS OR EXCEPTION	S				
3. Master Fire Warning Bell Cutout Switch	C 2	1	all o warni	may be inoperative ther components of ng system, both vis , operate normally	the fire sual and				
4. Lavatory Smoke Detection Systems			lavat a b c d NOTE	 O)May be inoperational or provided the association of the existence of the existen	ssociated: tinguisher es normally. eceptacle is locked rded "IN- OT ENTER", used for any are not clude lava- s by crew- e detection equired for				

FED	ERAL AVIATION ADMINI	STR	ATION		MASTER MINIMUM EQUIE	PMENT LIST
AIR	CRAFT:				REVISION NO: 37	PAGE:
	B-707 AND B	-720	0		 DATE: 10/19/90	27-1
		1.	2.	NUMBE	R INSTALLED	
SEQ	TEM & UENCE ITEM IBERS		 	3.]	NUMBER REQUIRED FOR DISPATO	 СН
 27	FLIGHT CONTROLS				4. REMARKS OR EXCEPTIONS	
1.	Rudder Boost Hydraulic System				Deleted, Rev. 37	
2.	Rudder Boost Hydraulic Pressure Reducer					
	1) Parallel Yaw Damper System	С	1	0	*(M)(O)May be inoperative a) System is rendered ative above 250 KI b) Boeing Service Bul has been incorpora	l inoper- AS, and letin #952
	2) Series Yaw Damper	С	1	0	*(0)May be inoperative pr limitations are observed.	
3.	Stabilizer Trim Actuator System				Deleted, Rev. 37	
4.	Stabilizer Main Electrical Trim Operating Light	С	 1 	 0 	<pre>*May be inoperative provi control wheel trim switch operates normally.</pre>	
5.	Mach Trim System				Moved to ATA 22.	
б.	Wing Trailing Edge Flap Position Indicator Needles	С	4 	 3 	*(0)One may be inoperative either flap gauge provide a) Flaps operate norm b) Flap position is ve before each takeof landing.	ed: mally, and verified
7.	Leading Edge Flap Position Light System	С	2	 0 	<pre>*(0)May be inoperative pr position of Leading Edge is verified before each t and landing.</pre>	devices

FEDERAL AVIATION ADM	INISTRA	ATION		MASTER MINIMUM EQU	IPMENT LIST	
AIRCRAFT:				REVISION NO: 37	 PAGE:	
B-707 ANI) В-720)		 DATE: 10/19/90	27-2	
	1.	2.1	NUMBEI	INSTALLED		
SYSTEM & SEQUENCE ITH NUMBERS	EM 		3. NUMBER REQUIRED FOR DISPATCH			
27 FLIGHT CONTROLS			ļ	4. REMARKS OR EXCEPTION	S	
8. Takeoff Warning H System	Iorn 			Deleted, Rev. 37		
9. Control Wheel Tri Switch System	Lm C	2	 1 	*Copilot's may be inope vided stabilizer trim s operates normally.		
10. Stabilizer Trim Brake	C	1	 0 	*(M)May be inoperative ; brake and associated re are deactivated and sec	lease cable	
 Reverser Actuated Leading Edge Flag Retraction System (RABS) 	os					
1) Turbine Rever- sers Installed		1	0 	<pre>*(M)May be inoperative ; a) Leading edge fla; normally, and b) Leading edge fla; adjacent wing sk are inspected fo; damage before ea; departure.</pre>	ps operate ps and in panels r heat	
2) Turbine Rever- sers Deleted o Deactivated	- 1	1	0	*May be inoperative pro- turbine reversers have i or deactivated.		

FED	ERAL AVIATION ADMIN	ISTR	ATION		MASTER MINIMUM EQUIP	MENT LIST
 AIR	 CRAFT:				REVISION NO: 37	 PAGE:
	B-707 AND	B-72(D		 DATE: 10/19/90	28-1
		1.	2.		R INSTALLED	
SEÇ	TEM & UENCE ITEM BERS	I	 		NUMBER REQUIRED FOR DISPATC	
	 FUEL		İ	İ	4. REMARKS OR EXCEPTIONS	
1.	Pressure Fueling System	С	 1 	0	*May be inoperative provi nate procedures are estab used.	
2.	Main Tank Fuel Boost Pumps	С	 8 	 7 	*(0)One may be inoperativ vided operations are cond compliance with the AFM.	-
3.	Center Tank Fuel Boost Pumps	С	2	0	*May be inoperative provi a) Center tank fuel i required, and b) Fuel in associated is included in the weight. OR	s not tank(s) zero fuel
		С			c) Associated tank re empty.	mains
4.	Main Tank Fuel Pressure Warning Lights	В	8	4 	<pre>*(M)One per tank may be i tive provided: a) Fuel pressure indi operate normally, b) Pump output is ver normal for each op pump before depart</pre>	cators and ified erative
		В	8	7	*(0)One may be inoperativ craft without fuel pressu indicators provided that takeoff, initial climb, a ing, associated tank is m to a tank with two operat pumps.	re during nd land- anifolded

U.S	. DEPARTMENT OF TRA	NSPOI	RTATI	ON NC					
FED	ERAL AVIATION ADMIN	ISTRA	ATION		MASTER MINIMUM EQUIPMENT	LIST			
AIR	CRAFT:				REVISION NO: 37	PAGE:			
	B-707 AND 1	B-720	0		DATE: 10/19/90	28-2			
		1.	2.1	NUMBEI	R INSTALLED				
SEQ	SYSTEM & SEQUENCE ITEM NUMBERS			3.1	3. NUMBER REQUIRED FOR DISPATCH				
 28	FUEL				4. REMARKS OR EXCEPTIONS				
5.	Center Tank Fuel B Pressure Warning Lights C		2 	0 	*(M)May be inoperative provid a) A procedure is used to verify associated pump put. OR				
		С	 		b) Tank does not contain fuel.	usable			
б.	Fuel Pressure Indicators	С	 4 	0	*May be inoperative provided fuel pressure warning system operates normally.				
7.	Reserve Fuel Transfer Lights	С	 2 	 0 	*May be inoperative provided reserve tank and main tank qu gauges operate normally.	antity			
8.	Reserve Fuel Transfer Valves	С	 2 	 0 	<pre>*(M)(O)May be inoperative pro a) Valves are secured clo and b) AFM procedures for fue loading and management observed.</pre>	sed, l			
					NOTE: Associated reserve tank is unusable and unjetti able.				

U.S. DEPARI	MENT OF TRAN	SPOF	RTATIO	ON			
FEDERAL AVI	ATION ADMINI	STR	ATION		MASTER MINIMUM EQUIPMENT LIST		
AIRCRAFT:					REVISION NO: 37 PAGE:		
	B-707 AND B	-720)		DATE: 10/19/90 28-3		
		1.	2.1	NUMBEF	R INSTALLED		
SYSTEM & SEQUENCE NUMBERS	ITEM		-	3. N	NUMBER REQUIRED FOR DISPATCH		
28 FUEL					4. REMARKS OR EXCEPTIONS		
9. Fuel Ma Valves	Fuel Manifold C Valves		4	3	*(M)One may be inoperative provided associated valve is secured open.		
					NOTE: Center tank to outboard fuel feed is not allowed for take- off with an inoperative inboard valve.		
10. Manifol Lights	d Valve	C C	4	3	<pre>*(M)One may be inoperative provided: a) Associated valve operates normally. OR b) Associated valve is secured</pre>		
11. Fuel Sh Valve I		С	4	3	open before departure. *(M)One may be inoperative provided associated valve operates normally with the fire switch, start lever, or flight engineer panel switch before each departure.		
12. Engine Positic	Fuel Valve n Lights				Moved to ATA-73.		
13. Fuel Ic Lights	ing Warning				Moved to ATA-73.		

FEDERAL AVIATION ADMINISTR	ATION		MASTER MINIMUM EQUIPM	ENT LIST
AIRCRAFT:			REVISION NO: 37	 PAGE:
B-707 AND B-72	0		 DATE: 10/19/90	28-4
1.	2.		R INSTALLED	
SYSTEM & SEQUENCE ITEM NUMBERS		3.1	NUMBER REQUIRED FOR DISPATCH	
28 FUEL			4. REMARKS OR EXCEPTIONS	
14. Fuel Dump System C	2		<pre>*(0)One may be inoperative provided: a) Weight over 105% of landing weight is c. center section tank, of fuel dumping, and b) Fuel usage and struel limits are observed</pre>	maximum arried in s capable d ctural
С	2 	0 	 *(M)(O)May be inoperative p a) Takeoff gross weigh not exceed 105% of p landing weight, b) Airplane performance quirements are satistication including approach landing climb capab and c) Jettison valves are CLOSED. 	t does maximum e re- sfied, climb and ility,
15. Fuel Tank Quantity C Gauge Totalizer		0	*	
16. Fuel Quantity C Indicators (Main Tanks)		3 	*(M)One may be inoperative provided: a) Dripstick readings to determine fuel q in tank with inoper gauge after each re	uantity ative
			(Continued)	

						MASTER MINIMUM EQUI	PMENT LIST				
FED	ERAL AVIATION AD	MINISTRA	TION								
AIR	CRAFT:					REVISION NO: 37	PAGE:				
	B-707 A	ND B-720	1			DATE: 10/19/90	28-5				
					R INSTA						
	YSTEM & ITEM		-	3. NUMBER REQUIRED FOR DISPATCH							
NUM	BERS		ļ	-		MARKS OR EXCEPTIONS					
	FUEL				4. KE	MARKS OR EACEPIIONS					
16.	Fuel Quantity Indicators (Main Tanks) (C	ont'd)			c) If airplane is no with operating fu totalizers, addit equal to at least required reserves fuel carried whice addition to fuel flight to destina carried. If unca fuel flow totaliz used, additional to at least 5% of required reserves carried. If cali flow meter is use crew furnished wi tion information, able, no addition required,) Fuel flow reading consumption rates logged,) Fuel loading and schedule in AFM i and) All boost pumps f ated tank are ope 	el flow ional fuel 10% of FAA (i.e., h is in needed for tion) is librated ers are fuel equal the FAA is brated fuel d and the th calibra- if applic- al fuel is s and fuel are use s followed, or associ-				
17.	Center Tank Fue Quantity Gauge	1 C	1	0		ay be inoperative p) Tank is emptied a with a known quan fuel.	nd serviced				
		C 			k	OR) Dripstick reading to determine fuel in associated tan each refueling. OR	quantity				
		C			С) Associated tank r empty.	emains				

T:				REVISION NO: 37	PAGE:
B-707 AND B	-720)		 DATE: 10/19/90	28-6
	 1.	2.1		R INSTALLED	
SYSTEM & SEQUENCE ITEM NUMBERS			3. N	NUMBER REQUIRED FOR DISPATCH	
 L	 			4. REMARKS OR EXCEPTIONS	
Fuel Quantity Reserve Tank Gauge		2	0	*May be inoperative provided a) Associated main tank and transfer valve li operates normally. OR	gauge
	C			<pre>b) Associated tank(s) re empty.</pre>	mains
-	C	1	0	*May be inoperative provided Air Temperature (TAT) or Ram Temperature (RAT) is substit as an indication of fuel tem ature.	Air uted
k Suppression					
707/720 (Except	C	-	0	*(M)May be inoperative provi auxiliary vent system (AD 67 is installed and operates no	-23-2)
	C	-	0	*	
-	C	-		<pre>*(M)May be inoperative provi a) There is no evidence leakage, and b) Refueling service equ is checked for moistu accumulation before a after each fuel servi</pre>	of ipment re nd
	£ E ITEM L l Quantity erve Tank Gauges	1. % ITEM I Quantity C erve Tank Gauges C l Tank Temper- C re Indicator Wall Fuel Surge k Suppression tem All Models C 707/720 (Except 707-300B & C) Models C 1 Sump Drain C	E ITEM E ITEM Quantity C 2 erve Tank Gauges C C 1 Tank Temper- C 1 re Indicator Wall Fuel Surge k Suppression tem All Models C - 707/720 (Except 707-300B & C) Models C - 1 Sump Drain C -	1. 2. NUMBER E ITEM 3. N E ITEM 3. N I Quantity C 2 0 I Quantity C 2 0 erve Tank Gauges C 1 0 I Tank Temper- C 1 0 re Indicator C 1 0 wall Fuel Surge Numbers 0 0 All Models C - 0 707/720 (Except 0 0 0 Models C - 0 Nodels C - 0 I Sump Drain C - 0	1. 2. NUMBER INSTALLED E ITEM 3. NUMBER REQUIRED FOR DISPATCH

						MASTER MINIMUM EQUIPM	ENT LIST			
FEDERAL AVIA	TION ADMINI	ISTR <i>i</i>	ATION							
AIRCRAFT:						REVISION NO: 37	PAGE:			
	B-707 AND E					DATE: 10/19/90				
			2.1	NUMBE	R INS	TALLED				
SYSTEM & SEQUENCE NUMBERS	ITEM			3. NUMBER REQUIRED FOR DISPATCH						
 28 FUEL					4. H 	REMARKS OR EXCEPTIONS				
22. Fuel Dri	psticks	C	-	 0 	fue	I)May be inoperative provided el quantity is verified by an ernate means.				
23. Fuel Hea Position		C	4	 0 	* 					
24. Fuel Hea	ter Valves	С	4	0		<pre>y be inoperative closed vided: a) Fuel tank temperatu: maintained at or ab degrees C. OR b) Engine fuel tempera not permitted to fa +5 degrees C.</pre>	ove O ture is			

FED	ERAL AVIATION ADMINI	STR	ATION		MASTER MINIMUM EQUIP	MENT LIST
AIR	 CRAFT:			REVISION NO: 37	PAGE:	
	B-707 AND B	-72(C		 DATE: 10/19/90	29-1
		1.	2.	-	R INSTALLED	
SEQ	TEM & UENCE ITEM BERS				NUMBER REQUIRED FOR DISPATC	Ή
 29	HYDRAULIC POWER				4. REMARKS OR EXCEPTIONS	
1.	Engine Driven Hydraulic Pumps					
	1) Depressurizing Function	С	2 	0	*(M)May be inoperative pr a) Associated valve i open, and b) The supply shutoff operative.	s verified
2.	Engine Driven Pump Supply Shut-off				Deleted, Rev. 37	
3.	Utility System Depressurizing Valv		 1 	0	*(M)May be inoperative pr valve is secured closed.	ovided
4.	Hydraulic System Interconnect Valve	С	 1 	0	*(M)May be inoperative pr valve is secured closed.	rovided
5.	Auxiliary Pumps				 Deleted, Rev. 37	
6.	D.C. Hydraulic Pump	С	1	0	*	
7.	High Pressure Air Start Compressor System	С	 1 	0	*	
8.	Brake Interconnect Valve	С		0	*(M)(O)May be inoperative a) Alternate procedur included in the AF utility system hyd malfunctions, and b) Valve is deactivat	res are M for Iraulic

FED	ERAL AVIATION ADMIN	ISTR	ATION		MASTER MINIMUM EQUI	IPMENT LIST			
AIR	 CRAFT:				REVISION NO: 37	PAGE:			
	B-707 AND	B-720		 DATE: 10/19/90	29-2				
		1.		NUMBE	R INSTALLED				
SEQ	TEM & UENCE ITEM BERS		 	NUMBER REQUIRED FOR DISPAT					
 29	 HYDRAULIC POWER		 		4. REMARKS OR EXCEPTIONS	5			
9.	Cockpit Utility System Pressure Ga	uge			 Deleted, Rev. 37 	eted, Rev. 37			
10.	Utility Hydraulic Pump Pressure Warning Lights	С	2 		<pre>*(M)(O)One may be inoper provided:</pre>	output is ormal before a operates			
11.	Auxiliary Hydraulic Power Warning Lights	С	2	1	*No. 2 pump warning ligh be inoperative. 	nt may			
	arning Lights	C	2	1 	<pre>*No. 1 pump warning ligh inoperative provided:</pre>	during			
12.	Utility Reservoir Quantity Gauge				Deleted, Prior to Rev. 3	37			
13.	Utility System Overheat Warning Light	C	1 	0	*				
14.	Auxiliary, Utility and Brake Accumula Pressure Gauges (Wheel Well)		2 	 	*(M)May be inoperative r charge is verified withi before each departure. 				

FEDERAL AVIATION ADMINIS AIRCRAFT: B-707 AND B-				
			REVISION NO: 37	 PAGE:
	-720		 DATE: 10/19/90	 29-3
-		NUMBER	R INSTALLED	
SYSTEM & SEQUENCE ITEM			NUMBER REQUIRED FOR DISPATC	 Н
NUMBERS		.	4. REMARKS OR EXCEPTIONS	
29 HYDRAULIC POWER				
15. Rudder Boost Pressure Indicator			Deleted, Prior to Rev. 37	
<pre>16. Brake Pressure Gauge (Cockpit)</pre>	C 1		<pre>*May be inoperative provi- a) Utility System pre gauge operates nor b) Brake interconnect operates normally, c) One indication of 1 tem pressure (gaug light) is availabl pilot's forward pa d) Accumulator pressu verified adequate 1 each departure.</pre>	ssure mally, valve brake sys- e or e on nel, and re is

FED	ERAL AVIATION ADMINI	ISTR <i>i</i>	ATION		MASTER MINIMUM EQUIPMENT LIST
AIR	CRAFT:				REVISION NO: 37 PAGE:
	B-707 AND B	3-720	C		DATE: 10/19/90 30-1
		1.	2.1	NUMBEI	R INSTALLED
SEQ	TEM & UENCE ITEM BERS		. 	3. 1 ·	NUMBER REQUIRED FOR DISPATCH
30	ICE AND RAIN PROTECTION				4. REMARKS OR EXCEPTIONS
1.	Wing Anti-Icing Duct Temperature Indicating System	С	2	0 	*May be inoperative provided associated valve position lights operate normally before departure in known or forecast icing conditions.
2.	Wing Anti-Icing System	С		 0 	<pre>*(M)May be inoperative provided: a) The airplane is not operated in known or forecast icing conditions, and b) Inoperative valve remains closed. OR</pre>
		С			 c) In addition to a), damaged ducting is removed, and d) A suitable blocking plate is installed.
3.	Wing Anti-Ice Valves	С	4	3	*(M)One may be inoperative secured closed.
4.	Empennage De-Icing System	С	1	0	*
5.	Empennage De-Icing Automatic Control			0	*
б.	Engine Anti-Icing System (Includes al Components and Indicators except Valves)	C	4	- 	<pre>*(M)(O)One light may be inoperative provided: a) All valves are verified to be operating normally before each departure, and b) Flight crew verifies valve operation by reference to EPR indication.</pre>

FED	ERAL AVIAI	ION ADMIN	NISTRA	ATION		MASTER MINIMUM EQUIPM	IENT LIST
AIR	CRAFT:					REVISION NO: 37	PAGE:
	E	8-707 AND	в-720)		DATE: 10/19/90	30-2
			1.		R INSTALLED		
					NUMBER REQUIRED FOR DISPATCH		
 30	ICE AND F					4. REMARKS OR EXCEPTIONS	
7.	PROTECTION Engine Anti-J Valves	ti-Ice	С	12	 11 	<pre>*(M)One may be inoperative closed provided:</pre>	operated st icing
			C 2			I contraction of the second second second second second second second second second second second second second	the JT3D -ice open e does not rees F (+5 ed engine ows: rees F prees C) 7, No
						F (+10 d	ons. 0 degrees legrees C) .07 EPR.
						and All atures, Other decreme Ratings: Max.Co	temper- use EPR ent from ontinuous setting n AFM,
						(Continued)	

FEDE	RAL AVIATION ADMINI	STRA	ATION		MASTER MINIMUM EQUIP	MEINI LIDI
AIRC	 RAFT:				REVISION NO: 37	PAGE:
	B-707 AND B	-720)		 DATE: 10/19/90	30-3
		 1.	2.1	NUMBEI	R INSTALLED	
	EM & ENCE ITEM ERS		-	3.1	JUMBER REQUIRED FOR DISPATCH	 H
	ICE AND RAIN PROTECTION				4. REMARKS OR EXCEPTIONS	
	Engine Anti-Ice Valves (Cont'd)				c) Limiting gross weig reduced by:	ghts are
					Takeoff & Landing: (4,309 kg) - applic above +50 degrees D degrees C)	cable
					En Route Climb (1 of engines inoperative lb. (5,443 kg) a eratures, and d) On the remaining th engines, all anti- operate normally.	e): 12,000 all temp- hree
					NOTE: Use of the turbo cor on the JT3D engine : hibited in the land: figuration without a operating flight id light.	is pro- ing con- an
8.	Pitot Heaters				Deleted, Rev. 37	
	Flight Deck Window Heating Systems	C	10	-	*(O)May be inoperative pro limitations are complied w	
	Rain Repellent System	С	1	0	*	
11.	Windshield Wipers	С	2	0	*May be inoperative provid airplane is not operated : precipitation within 5 nat miles of the airport of ta intended landing.	in utical

EDERAL AVIATION ADM	INISTR	ATION			MASTER MINIMUM EQU	IPMENT LIST	
IRCRAFT:				 	REVISION NO: 37	PAGE:	
B-707 AN	D B-72	0			DATE: 10/19/90	30-4	
	1.	2.	NUMBEI	R INST	ALLED		
YSTEM & EQUENCE IT UMBERS	 	3.1	NUMBER	REQUIRED FOR DISPA	 ТСН 		
0 ICE AND RAIN PROTECTION				4. R 	. REMARKS OR EXCEPTIONS		
2. "Q" Inlet Heater	С	 1 	0		May be inoperative tations are complie		
				NOTE	 If icing conditio encountered inadv For airplanes i series yaw damp large rudder in speeds above 25 For airplanes i parallel yaw da rudder boost OF above 250 KIAS, speeds below 25 	ertently: ncorporating er, avoid puts at 0 KIAS. ncorporating mper, turn F at speeds and ON at	
3. Ice Detector System	С	 1 	0	 * 			
4. Attitude Warning Heat System	С	2 	0	plan	be inoperative pro e is not operated i cast icing conditio	n known or	
5. Pitot Heat Ammet or Light	er B	2		prov 	One may be inoperat ided: a) All other compon pitot heat syste normally, and b) The airplane is in visible moist known or forecas conditions.	ents of the m operate not operated ure or in	

FEDERAL AVIATION ADMINISTR	ATION			MASTER MINIMUM EQUI	PMENT LIST			
AIRCRAFT:				REVISION NO: 37	 PAGE:			
B-707 AND B-72	0			DATE: 10/19/90	 30-5			
	2.	NUMBEI	R INST	ALLED				
SYSTEM & SEQUENCE ITEM NUMBERS		3.1	NUMBER	REQUIRED FOR DISPAT	 CH 			
30 ICE AND RAIN PROTECTION			4. REMARKS OR EXCEPTIONS 					
L6. TAT Probe Heater C	1 	 0 		be inoperative prov a) The airplane is no in known or foreca conditions. OR b) An alternate temp	ot operated ast icing erature			
17. Pitot Heat B Indicating "Heater Off" System			 	system is operative May be inoperative p: a) All other component pitot heat system normally, and b) The airplane is not in visible moistur known or forecast conditions.	rovided: nts of the operate ot operated re or in			

'EDERAL AVIATION	ADMINISTRA	ATION		MASTER MINIMUM EQUIPN	IENT LIST
IRCRAFT:				REVISION NO: 38	PAGE:
B-70	7 AND B-720	D		 DATE: 11/14/90	 31-1
	1.	2.1	NUMBEI	R INSTALLED	
YSTEM & EQUENCE IUMBERS	ITEM		3.1 -	NUMBER REQUIRED FOR DISPATCH	 I
1 INDICATING/R SYSTEMS	ECORDING			4. REMARKS OR EXCEPTIONS	
. Clock	C	 – 	 1 	 *One may be inoperative at pilot's or co-pilot's stat 	
2. Flight Data Recorder (FDR System	Α			<pre>*May be inoperative provid a) Cockpit Voice Recon operates normally, b) Repairs are made wi three flight days.</pre>	rder (CVR) and

ED	ERAL AVIATION ADMINIS	STR	ATION		MASTER MINIMUM EQUIPN	MENT LIST				
 IR	CRAFT:				REVISION NO: 37	PAGE:				
	B-707 AND B	-720)		DATE: 10/19/90	32-1				
		1.	2.1	NUMBEI	INSTALLED					
SYSTEM & SEQUENCE ITEM IUMBERS				3.1	MBER REQUIRED FOR DISPATCH	I				
	LANDING GEAR				4. REMARKS OR EXCEPTIONS					
•	Landing Gear Door Warning System		1	0 	*(O)May be inoperative pro gear doors are verified c before takeoff, after take after landing.	losed				
•	Landing Gear Ground Lock Pin Annunciator	C	-	 0 	*					
•	Anti-Skid System	C	1	 0 	*(M)(O)May be inoperative AFM antiskid inoperative p and performance data are o	procedures				
•	Pneumatic Brake System				Deleted, Rev. 37					
•	Pneumatic Brake Pressure Gauge (Nose Wheel Well)	С	1	 0 	*					
•	Parking Brake				Deleted, Rev. 37					
•	Parking Brake Light	С	1	 0 	*(M)May be inoperative pro parking brake valve operat normally.					
•	Landing Gear Warning and Indicating Syste			 	Deleted, Rev. 37					
				İ						
				İ						
				İ						

FED	ERAL AVIATIO	ON ADMINISTR	ATION		M	ASTER MINIMUM EQUI	IPMENT LIST	
AIR	CRAFT:			 R	EVISION NO: 38	PAGE:		
	в-'	707 AND B-72	0	 [DATE: 11/14/90	33-1		
		1.	2. 1	NUMBEI	r instal	LED		
SEQ	YSTEM & EQUENCE ITEM UMBERS			 3.1 .	3. NUMBER REQUIRED FOR DISPATCH			
 33	LIGHTS				4. REM 	ARKS OR EXCEPTIONS	5	
ι.	Flight Comp and Instrum Lighting	partment C ment		-	ative are: a) b)	ridual lights may by provided remaining Sufficient to cle illuminate all in and switches, Positioned so that rays are shielded member's eyes, an Of controllable : unless this featu proven unnecessan	g lights early nstruments at direct d from crew- nd intensity, ure is	
2.	Passenger Notice C System ("No Smoking /Fasten Seat Belt/ Return to Cabin") Signs	– 		dant s pied f Fasten sign i seat c)No passenger, cal eat or lavatory ma rom which a "No Sr Seat Belt/Return s not readily leg: or lavatory must be acarded - "DO NOT	ay be occu- noking/ to Cabin ible or that e blocked		
		C			Return inoper enger seat(s ied pr a) 	to Smoking/Fasten S to Cabin" signs r rative and the affe seat(s), cabin att or lavatories ma rovided: PA System operate and can be clear throughout the ca flight, and PA system is used the cabin crew an the passengers wh belts should be f smoking is prohib	may be ected pass- cendant ay be occup- es normally by heard abin during d to alert nd to notify hen seat Eastened and	
	1) Aural To System	one C	1	0	 * 			

ED	ERAL AVIATION ADMINI	STR	ATION			MASTER MINIMUM EQUIPME	ENT LIST				
 ER	CRAFT:					REVISION NO: 38	PAGE:				
	B-707 AND E	3-72	0			DATE: 11/14/90	33-2				
_		1.		NUMBER INSTALLED							
EQ	TEM & UENCE ITEM BERS					R REQUIRED FOR DISPATCH					
 3 LIGHTS				4. REMARKS OR EXCEPTIONS							
	Cabin Interior Illumination	С	 – 	 - 	erat is s)Individual lights may b tive provided remaining sufficient for cabin att perform their duties.	lighting				
	Cargo Compartment Light System	С	 - 	0	1	y be inoperative in Clas partments.	ss "D"				
	Tail Compartment Light	С	 1 	0	 * 						
	Air Conditioning Compartment Lights	С	 - 	0	 * 						
	Lower Nose Compartment Lights	-	 - 	0	 * 						
	Wheel Well Lights (Main Gear Wheel Well)	С	 2 	0	with	y be inoperative for aim an alternate landing o icating system.					
	High Intensity Oscillating Navigation Lights (Position Lights)	С	– 	 0 	* 						

EDERAL AVI	ATION ADMIN	ISTR	ATION		MASTER MINIMUM EQUIP	MENT LIST				
AIRCRAFT:					REVISION NO: 37	PAGE:				
	B-707 AND	B-720)		 DATE: 10/19/90	 33-3				
		1.	2.	NUMBEI	MBER INSTALLED					
SYSTEM & SEQUENCE	EQUENCE ITEM UMBERS 			3.1	NUMBER REQUIRED FOR DISPATC					
				.	4. REMARKS OR EXCEPTIONS					
33 LIGHTS				ļ						
.0. Runway 1 Lights			_	0 	*May be inoperative provided landing lights on the same side of the airplane as inoperative turn- off light(s) operate normally.					
		C	-	0	*May be inoperative for d operations.	ay				
1. Landing	Landing Lights		4	2	*One on each side may be inoperative.					
		С	4	0	*May be inoperative for d operations.	ay				
2. Taxi Lig	ght	С	-	0	*					
.3. Anti-Co Beacon	Anti-Collision		2	 1 	*One may be inoperative p high intensity oscillatin strobe anti-collision (wi mounted) lights operate n	g or ng/tail				
		С	2	0	*May be inoperative provi Minneapolis-Honeywell air recognition light system normally.	craft				
		С	2	0	*May be inoperative for d operations.	ay				
.4. Wing Il: Lights	lumination	С	2	0 	*May be inoperative provi portable lamp/light of ad capacity for wing and/or surface inspection is ava for night operations in i conditions.	equate control ilable				

FEDE	RAL AVIATIO	ON ADMINISTRA	ATION			MASTER MINIMUM EQUI	PMENT LIST
AIRC	RAFT:				REVISION NO: 37	 PAGE:	
	В-	707 AND B-720)			DATE: 10/19/90	33-4
		1.	2.1	NUMBEI	R INST	 FALLED	
SEQU	SYSTEM & SEQUENCE ITEM IUMBERS		. 	3.1	NUMBEF	R REQUIRED FOR DISPAT	 СН
	3 LIGHTS			4.F		REMARKS OR EXCEPTIONS	
	Position L: (Wing tips	ights C and Tail)		3 		 r night operations, a following may be ino a) One stationary re light, b) One stationary gr tip light, and c) One stationary wh light. 	perative: d wing tip een wing
		C	-	0		y be inoperative for rations.	day
	Interior Er Lighting Sy (Including Exit Lights	Emergency	1	 	*(M) 	 May be inoperative p a) Airplane is opera all cargo configu b) Forward entry lig normally, and c) Forward emergency lights operate no 	ted in an ration, hts operate r exit
	Exterior En	nergency B ystem		0		y be inoperative for rations.	day

FEDERAL AVIATION ADMIN	IISTRA	TION			MASTER MINIMUM EQUI	PMENT LIST
AIRCRAFT:					REVISION NO: 37	 PAGE:
B-707 AND	в-720)			 DATE: 10/19/90	 33-5
					 TALLED	
SYSTEM & SEQUENCE ITEM		2.1			R REQUIRED FOR DISPAT	сн
NUMBERS	 		-	4. REMARKS OR EXCEPTIONS		
33 LIGHTS						
Emergency Escape Path Marking System	1	1	inop min: in (dividual lights may b perative provided FAA imum acceptable light one of the following uments are complied w a) FAA engineering a letter. OR	approved ing levels ith:	
	C				b) FAA approved repo Type Design holde OR	
	C 				c) Limitations and C section of the ap Supplementary Typ Certificate (STC) OR	plicable e
	C 				d) An FAA report inc in the Master Dra for the applicabl	wing List

FED	ERAL AVIATION ADMI	NISTRA	ATION			MASTER MINIMUM EQUI	IPMENT LIST			
AIR	 CRAFT:					REVISION NO: 37	PAGE:			
	B-707 AND	B-720)			DATE: 10/19/90	 34-1			
		1.	2.	NUMBER INSTALLED						
SEQ	TEM & UENCE ITE BERS	M		3.1		REQUIRED FOR DISPAT				
 34	NAVIGATION				4. r 	EMARKS OR EXCEPTIONS	5			
1.	Airspeed Indicato (IAS)	rs			 Dele	eted, Prior to Rev. 3	37			
2.	True Airspeed Indicator (TAS)	C	-	0	 * 					
3.	Mach/Airspeed Indicators									
	1) Mach Indicatio	ns C	2		Mach	e may be inoperative n/Airspeed Warning ar rate normally.	-			
		С	2			 be inoperative prov a) Flight remains at FL 220, b) Airspeed does not 350 KIAS, and c) A placard which s this limitation i to the instrument 	t or below t exceed sets forth is affixed			
ł.	Mach/Airspeed Warning System	С	1	0 	ĺ	 May be inoperative p a) Mach trim inoperative p limitations are of b) Aural warning abore trim inoperative operates normally c) Both Mach indicate normally, and d) Airspeed does note value at which auring would sound. 	ative AFM observed, ove mach speed 7, cors operate c exceed the			
5.	Altimeters				 Dele 	eted, Rev. 37				

다	ERAL AVIATION ADMIN	ד פידים ד	מתיד∩זי		MASTER MINIMUM EQUI	PMENT LIST					
AIR	CRAFT:				REVISION NO: 37 						
	B-707 AND 1	B-72(0		DATE: 10/19/90	34-2					
qvq	TEM &	1.	2.	NUMBE	NUMBER INSTALLED						
SEQ	UENCE ITEM			3.1	NUMBER REQUIRED FOR DISPAT	СН					
	BERS				4. REMARKS OR EXCEPTIONS						
34	NAVIGATION										
6.	Altimeter Vibrator	S									
	1) Servo Pneumatic	С	2	1	*One may be inoperative p associated air data comp function operates normal	uter					
	2) Pneumatic	С	 2 	1	 *One may be inoperative] VMC conditions exist at o and arrival airports.						
7.	Rate of Climb Indicators				Deleted, Rev. 37						
8.	Static Air Temperature (SAT) Indicator		 1 	0	*May be inoperative prov Air Temperature (TAT) ind operates normally.						
9.	Ram Air Temper- ature (TAT) Indicator	С	 1 	0	*May be inoperative prov Air Temperature (SAT) ind operates normally.						
10.	Bank and Pitch Indicator (Horizon Indicator)				 Deleted, Prior to Rev. 3 	7					
11.	Vertical Gyro Syst	em	 		 Deleted, Prior to Rev. 3	7					
12.	Attitude Warning System	С	 2 	0 	<pre>*May be inoperative prov: procedures and limitation observed.</pre>						
13.	Angle of Attack Indicators	C	 2 	0	<pre>*May be inoperative prov: procedures and limitation observed.</pre>						
14.	Turn and Slip Indicators	С	 2 	1 	 *Turn function of one in: may be inoperative for da operations only. 						
		С	 2 	0	 *May be inoperative prov by Horizon operates norma						

FEDERAL AVIATION	ADMINISTE	ATION	ſ	MASTER MINIMUM EQUI	PMENT LIST		
AIRCRAFT:			REVISION NO: 37	 PAGE:			
B-707	AND B-72	0		 DATE: 10/19/90	DATE: 10/19/90 34-3		
	1.	2.	NUMBE	R INSTALLED			
SYSTEM & SEQUENCE NUMBERS	ITEM		3.1	NUMBER REQUIRED FOR DISPAT	 Сн 		
 34 NAVIGATION	4. R						
15. Directional G Compass Syste	-			 Deleted, Rev. 37 			
<pre>16. Non-Stabilize Magnetic Comp (Standby)</pre>	Non-Stabilized B Magnetic Compass		0	*May be inoperative prov combination of three gyr (IRU) stabilized compass are operative.	o or INS		
	В	1		<pre>*(0)May be inoperative p a) Any combination o or INS (IRU) stab compass systems a operative, and b) Airplane is opera dual independent capability, and u positive radar co ATC on the enrout of the flight.</pre>	f two gyro ilized re ted with navigation nder ntrol by		
	С			*(0)May be inoperative f that are entirely within magnetic unreliability p least two stabilized dir gyro systems operate nor are used in conjunction approved free gyro navig techniques.	areas of rovided at ectional mally and with		
17. Flight Direct System	cor C	– 	-	<pre>*May be inoperative prov approach minimums do not its use.</pre>			
18. Distance Meas Equipment (DM		1	-	*As required by FAR.			
19. Marker Beacor	n C	 1 	– 	 *May be inoperative prov approach minimums do not its use.			

FEDERAL AVIATION ADMI	NISTRA	ATION	Ī	MASTER MINIMUM EQUIP	MENT LIST		
AIRCRAFT:				REVISION NO: 37	PAGE:		
B-707 AND	B-720	C		 DATE: 10/19/90	34-4		
	1.	2.	NUMBEI	R INSTALLED			
SYSTEM & SEQUENCE ITE NUMBERS	М		3.1	3. NUMBER REQUIRED FOR DISPATCH			
34 NAVIGATION				4. REMARKS OR EXCEPTIONS			
20. Doppler Navigatio System	n C	 – 	-	*As required by FAR.			
21. Inertial Navigation System		 – 	-	*As required by FAR.			
22. Weather Radar	С	 –	-	 *As required by FAR.			
23. Radio Compass (ADF)	С	 – 	-	*As required by FAR.			
24. VHF Navigation Receiver (VOR/ILS	C)	2	-	*As required by FAR.			
25. ILS				Deleted, Rev. 37			
26. ATC Transponder	С	2	-	 *As required by FAR. 			
27. Instrument Comparator or War Systems	C ning	 1 	0	*May be inoperative provi approach minimums do not its use.			
28. Air Data Systems (KIFIS or CADC)	C		0 	*May be inoperative provi a) Dispatch deviation affected equipment observed, and b) Affected equipment in this column of	s for are is listed		
29. Altitude Alerting System	В	-	-	*As required by FAR.			
30. Standby Attitude Indicator	В			*May be inoperative for d operations only.	ау VMC		

FED	ERAL AVIATION ADMINI	STR	ATION			MASTER MINIMUM EQUI	PMENT LIST
AIR	CRAFT:				REVISION NO: 38 PAGE:		
	B-707 AND B					DATE: 11/14/90	34-5
					R INST	 TALLED	
SEQ	SYSTEM & SEQUENCE ITEM NUMBERS					REQUIRED FOR DISPAT	
 34	NAVIGATION				4. H	REMARKS OR EXCEPTIONS	
31.	Automatic Altitude Reporting	С	2	 - 	 *As 	required by FAR.	
32.	Ground Proximity Warning System						
	1) Glideslope Deviation Lights		-	0	 * 		
	2) Mode 6 Warning (Minimums, Minimums)	C	1	0	* * 		
33.	VLF Navigation Receiver	С	-	-	*As 	required by FAR.	
34.	Radio Altimeter	С	 – 	 – 	appi	y be inoperative prov coach minimums do not use.	
35.	Traffic Collision and Avoidance System (TCAS)	С	-	 0 		May be inoperative p tem is deactivated an	
* * *	1) Combined Traffic Alert (TA) and Res- olution Advisory (RA) Dual Display		2	 1 		One may be inoperati flying pilot side pr a) TA and RA element functions are ope the flying pilot b) TA and RA display indications are v the non-flying pi	ovided: s and audio rative on side, and r isible to
					 (Cor 	ntinued)	

U.S. DEPARTMENT OF TRANSI	PORTATI	on	
FEDERAL AVIATION ADMINIS	TRATION		MASTER MINIMUM EQUIPMENT LIST
AIRCRAFT:			REVISION NO: 38 PAGE:
B-707 AND B-	720		DATE: 11/14/90 34-6
	. 2.	NUMBEI	R INSTALLED
SYSTEM & SEQUENCE ITEM NUMBERS		3.1	NUMBER REQUIRED FOR DISPATCH
34 NAVIGATION	-		4. REMARKS OR EXCEPTIONS
35. Traffic Alert Collision Avoidance System (TCAS) (Cont'd)			
2) Resolution (Advisory (RA) Display System(s)		1 	*(0)One may be inoperative on the non-flying pilot side.
(C -	0 	 *(O)May be inoperative provided: a) All Traffic Alert (TA) display elements and voice command audio functions are operative, and b) TA only mode is selected by the crew.
3) Traffic Alert ((TA) Display System(s)	c - 	0	*(O)May be inoperative provided all installed RA display and audio functions are operative.
36. Wind Shear Alerting System	C -		*May be inoperative until required by FAR, provided system is deactivated.

ספיט	ERAL AVIATION AD	мтитотр	᠕᠊᠋ᡣ᠇᠋᠊᠆ᡣᡕ			MASTER MINIMUM EQUIP	MENT LIST			
		MINISIR. 	AIION 							
AIRC	CRAFT:					REVISION NO: 37	İ			
	B-707 A	ND B-72	0 			DATE: 10/19/90	35-1			
SYSI	ГЕМ &	1.	2.	NUMBEI	R INS	FALLED				
	JENCE I BERS	TEM		3.1	NUMBEI	R REQUIRED FOR DISPATC	H 			
	OXYGEN			ļ	4. I	REMARKS OR EXCEPTIONS				
	Passenger Oxyge System	n C)The automatic presentation a) The manual deployment operates normally, b) The flight remains below FL 250. 	provided: ent system and			
		В			serv)(0)One or more passenging vice units (PSUs) may be without flight altitization provided: a) Affected seats are and placarded to proceed to provide to provide to provide to provide to provide to the providet to the provide to the providet to the provide to t	be inoper- tude blocked revent ally at y and			
		В			*(0	 May be inoperative provided in the second	ucted en route 14,000 ng packs ts of the tem mains at its are f the			

J.S. DEPARTMENT OF TRANSPO	RTATI	ON	
FEDERAL AVIATION ADMINISTR	ATION		MASTER MINIMUM EQUIPMENT LIST
AIRCRAFT:			REVISION NO: 37 PAGE:
B-707 AND B-72	20		DATE: 10/19/90 35-2
1. System &	2.	NUMBEI	R INSTALLED
SEQUENCE ITEM JUMBERS		3.1	JUMBER REQUIRED FOR DISPATCH
35 OXYGEN			4. REMARKS OR EXCEPTIONS
2. Passenger Oxygen B Mask Door Latch		- 	<pre>*(M)(O)Automatic door opening feature and/or latch may be inoperative unlatched and taped closed provided: a) No person(s) may occupy associated seat(s), and the seat(s) is blocked. OR</pre>
C			b) The flight remains at or below FL 250.
3. Passenger Oxygen C Pressure Indicator	1 	0	*(M)May be inoperative provided all cylinder gauges are checked to verify adequate pressure before departure.
4. PBE Smoke Hoods			Moved to ATA 25-4.

FEDE	RAL AVIATION ADMIN	IISTRA	ATION			MASTER MINIMUM EQUID	PMENT LIST
AIRC	RAFT:					REVISION NO: 37	PAGE:
	B-707 AND	B-720	D			DATE: 10/19/90	 36-1
		1.	2.1	NUMBEI	R INST	'ALLED	
SEQU	'EM & JENCE ITEM BERS	I		3.1		REQUIRED FOR DISPAT	сн
36	PNEUMATIC				4. R	EMARKS OR EXCEPTIONS	
	Hot Air Isolation Valve	С	1	0		May be inoperative pr e is secured open.	rovided the
	Wing Isolation Valves	olation C		 		<pre>may be inoperative p a) High pressure star available to isola of airplane, and b) With one pressuri: source, the airpla at or below 10,000 OR</pre>	rt is ated side zation ane remains
		С				c) With two pressuri: sources, in addit: the airplane rema: below 15,000 feet	ion to a), ins at or
3.	Duct Pressure Gauge	С	1	0	*		
	Inlet Duct Temperature Indica	C	1	0	temp	be inoperative prov erature function oper ally.	

FEI	DERAL AVIATIO	ON ADMINISTR	ATION			MASTER MINIMUM EQUI	PMENT LIST
AIF	CRAFT:					REVISION NO: 37	 PAGE:
	B-	707 AND B-72	0			 DATE: 10/19/90	52-1
		1.	2.	NUMBE	R INS	ΓALLED	
SEÇ	STEM & QUENCE IBERS	ITEM	 	3.]	NUMBEI	R REQUIRED FOR DISPAT	сн
 52	DOORS				4.1	REMARKS OR EXCEPTIONS	
1.		illet C ght System	 1 	 0 	a pi dooi)May be inoperative p rocedure is used to v r(s) is closed and lo n departure.	erify
2.	Main Cabin Pressure S Fittings	Door C top			with top miss and fith	 (O)The airplane may (O)The airplane may the upper aft OR fi forward fitting brok sing on the forward e /or one of the two up tings broken or missi entry door provided: a) There are no visi on other fittings associated door, b) Auto pressurizati troller operates and is used, and c) Pressure differen not exceed 5.9 ps 	fth-from- en or ntry door, per aft ng on the ble defects of on con- normally tial does
	Lower Cargo Pressure S Fittings	o Door A top		- 		 (O)Any one may be br sing provided: a) There are no visi on other fittings associated door, b) Auto pressurizati troller operates and is used, c) Pressure differen not exceed 5.2 ps d) Not more than 5 t and landings are to completion of 	ble defects of on con- normally tial does i, and akeoffs made prior
		С	– 	0 	prov	l may be broken or mi vided flight is condu ressurized configurat	cted in an

EDERAL AVIATION ADMINISTR	ATION		MASTER MINIMUM EQUIP	MENT LIST
IRCRAFT:			REVISION NO: 37	 PAGE:
B-707 AND B-72	0		 DATE: 10/19/90	52-2
1.	2.		R INSTALLED	
SYSTEM & BEQUENCE ITEM IUMBERS			NUMBER REQUIRED FOR DISPATC	
2 DOORS			4. REMARKS OR EXCEPTIONS	
. Main Cargo Door B Cam Hooks	2 	0	*(M)(O)May be broken or m provided each door latch visually inspected for pr engagement after each doo	is oper
6. Main Entry Door C Hold-Open Latch			*Latch release lever may for all-cargo operations	

EDERAL AVIATION ADMINIS	TRATION		MASTER MINIMUM EQUI	PMENT LIST
AIRCRAFT:			REVISION NO: 37	PAGE:
B-707 AND B-	720		 DATE: 10/19/90	 53-1
1	. 2.	 NUMBEF	INSTALLED	
SYSTEM & BEQUENCE ITEM IUMBERS		3. N	UMBER REQUIRED FOR DISPAT	
JUMBERS 53 FUSELAGE	-		4. REMARKS OR EXCEPTIONS	
Ventral Fin			*(M)May be missing or reprovided AFM requirements tions are observed.	

EDERAL AVIATION ADMINIST	RATION		MASTER MINIMUM EQUIPMENT LIST
IRCRAFT:			REVISION NO: 37 PAGE:
B-707 AND B-7	20		
1.	2.	NUMBEI	R INSTALLED
YSTEM & EQUENCE ITEM UMBERS		 3.1 -	NUMBER REQUIRED FOR DISPATCH
3 ENGINE FUEL & CONTROL		ļ	4. REMARKS OR EXCEPTIONS
. Engine Fuel Valve C Position Lights		0	 *
. Fuel Icing C Warning Lights	2 4	2	<pre>*(M)Two may be inoperative provided: a) Inoperative lights are not on the same side, b) Fuel temperature indicators operate normally, and c) Fuel heaters operate normally. </pre>

EDERAL AVIATION ADMINISTR	ATION		MASTER MINIMUM EQUI	PMENT LIST
IRCRAFT:			REVISION NO: 37	PAGE:
B-707 AND B-720)		 DATE: 10/19/90	74-1
1.	2.1	NUMBER	INSTALLED	
YSTEM & EQUENCE ITEM UMBERS	-	3. N	UMBER REQUIRED FOR DISPAT	
4 IGNITION		-	4. REMARKS OR EXCEPTIONS	
. Ignition Systems C	8		*(M)One per engine may be ative provided anti-ice of for associated engine are inoperative closed.	valve(s)

FED	ERAL AVIATIO	N ADMINI	ISTRA	ATION		MASTER MINIMUM EQUIE	PMENT LIST
AIR	CRAFT:				REVISION NO: 37	 PAGE:	
	B-7	07 AND E	3-72(C	 DATE: 10/19/90	 77-1	
			1.	2.1		R INSTALLED	
SEQ		ITEM				NUMBER REQUIRED FOR DISPATO	 СН
	BERS				.	4. REMARKS OR EXCEPTIONS	
/ /	ENGINE INDI	CATING					
1.	Tachometer	(N1)	В	4 	3 	*One may be inoperative p N2 and Fuel Flow Meter or ated engine operate norma	n associ-
2.	Tachometer	(N2)	В	4 	 	*(M)(O)One may be inopera provided: a) N1 and Fuel Flow M associated engine normally, and b) An alternate start cedure is used.	Meter on operate
3.	Engine Pres Ratio (EPR)		С	4	3	<pre>*(M)(O)One may be inoperative provided:</pre>	rocedures, performance plied, flow indi- ated engine cust set- vailable, re reduced d. intermix engine stems must
4.	EGT Indicat	ors				Deleted, Rev. 37	
5.	Vibration Indicating	System	С	 1 	 0 	 *May be inoperative unles by a maintenance procedum 	

FEDERAL AVIATION ADMINISTR	ATION		MASTER MINIMUM EQU	IPMENT LIST
AIRCRAFT:			REVISION NO: 37	 PAGE:
B-707 AND B-72	0		 DATE: 10/19/90	 77-2
 1.	2. 1	NUMBEF	R INSTALLED	
SYSTEM & SEQUENCE ITEM IUMBERS	. 	3.1	IUMBER REQUIRED FOR DISPA	
77 ENGINE INDICATING			4. REMARKS OR EXCEPTION	S
5. Fuel Flow Meters B	4	3	*One may be inoperative associated N1, N2 and f indicating system opera	uel quantity
7. Fuel Flow Meter C Power Supply (Normal or Alternate)		1	*	

FEDERAL AVIA	TION ADMINI	ISTRA	TION			MASTER MINIMUM EQU	IPMENT LIST
AIRCRAFT:						REVISION NO: 37	PAGE:
	B-707 AND B	3-720)			DATE: 10/19/90	 78-1
		1.	2. 1	NUMBEI	R INSI	'ALLED	
SYSTEM & SEQUENCE JUMBERS				 3.1	NUMBER	REQUIRED FOR DISPA	 ТСН
78 ENGINE E	XHAUST				4. r 	EMARKS OR EXCEPTION	S
l. Thrust R	eversers	C	4	2	prov 	<pre>Two may be inoperat: ided: a) No damage exists impair the struct operational integ reverser system of components, b) Operative reverse symmetrically opp c) Inoperative reverse secured in the for thrust position.</pre>	which would tural or grity of the or ers are posed, and rser(s) are
. Thrust Reverser Operating Lights		C	4	3	prov 	One may be inoperat: ided: a) Associated Thrust is secured in the thrust position, b) No damage exists impair the struct operational integ reverser system of components.	t Reverser e forward and which would tural or grity of the
		C	4			be inoperative for erative reversers.	associated

FED	PERAL AVIATION ADM	INISTR	ATION	I	MASTER MINIMUM	EQUIPMENT LIST
AIR	CRAFT:				REVISION NO: 3	 7 PAGE:
	B-707 ANI				 DATE: 10/19/90	 79-1
				NUMBE	R INSTALLED	
SEÇ	TEM & UENCE IT IBERS	EM			NUMBER REQUIRED FOR D	
 79	ENGINE OIL				4. REMARKS OR EXCEP	TIONS
1.	Oil Cooling Air Ejector	C	 4 	3	*One may be inopera associated oil temp ting system operate	erature indica-
2.	Oil Quantity Gauges	В	4 	3 	oil tank is mended capac b) There is no	ed before each at associated filled to recom- ity, evidence of oil consump- age, and il temperature indications
	Oil Pressure Indicators				Deleted, Rev. 37	
4.	Oil Low Pressure Warning Lights	В	4 	3 	*One may be inopera associated oil pres ture, and quantity normally.	sure, tempera-
5.	Oil Filter Bypas: Warning System	s C	4 	0	and b) Filter scree	is verified to rning system,
5.	Oil Temperature Indicators				Deleted, Rev. 37	

ΈĽ	ERAL AVIATION AD	MINISTRA	ATION		MASTER MINIMUM EQU	IPMENT LIST
IR	CRAFT:				REVISION NO: 37	PAGE:
	B-707 A	ND B-720	C		 DATE: 10/19/90	82-1
		1.	2.	NUMBE	R INSTALLED	
ΕÇ	TEM & UENCE I' BERS	TEM	 		NUMBER REQUIRED FOR DISPA	
2	WATER INJECTION				4. REMARKS OR EXCEPTION	S
	Water Injection System	С	 1 	0	*(O)May be inoperative dry takeoff performance ments are observed.	-
	Water Injection Master Shut-Off Valves		4	3 	<pre>*(M)(O)One may be inope provided:</pre>	re sed to
•	Compressor Inle Valves	t C	 4 	0	*(M)May be inoperative valve(s) are manually s desired position.	
•	Water Drain Val	ve C	1	0	*(O)May be inoperative a) Valve is placed b) Water supply is tanks to engines	OFF, and run dry from
	Water Injection Pump Lights	C	2		*One may be inoperative a) Water injection operative, and b) EPR, N1, N2 and systems on assoc engine(s) operat	system is Fuel Flow iated
		С	 2 	0	*May be inoperative pro injection is not used.	vided water
•	HALF FULL Light (Water Injection Quantity Lights	n		 0 	*May be inoperative for offs only. 	dry take-