

## Cadet Pamphlet Distributor Box Assembly Instructions

### Components

Before proceeding please confirm that you have the following components and quantities:

- Component A - Exterior box assembly - 1 unit
- Component B - Interior row separators - 3 units
- Component C - Interior column separators - 4 units

### Preparation of Components

**Component A - Box Exterior** (Note: Panels A1 & A2 are glued to form the perimeter of the box.)

1. Pop up box to be rectangular in shape (reference figure 1)
2. Pre-fold all flaps to make them flexible for assembly
3. Position the box upside down
  - a. Fold in the flaps in the following sequence
    - i. Fold flap B 90 degrees towards the inside of the box
    - ii. Similarly, fold flaps C such that they snap in and hold flap B in place
    - iii. Fold in flap D to the point where flap D tucks and locks under flap B
4. Position the box right-side up onto a flat surface
5. From within the box, flatten down the base
6. Fold all of flaps E 180 degrees to the inside of the box

**Component B - Interior row separators** - 3 units

1. Place as shown with indentations facing down (Ref Figure 5)
2. Fold both flaps 90 degrees forming a square U shape with the shorter side being the front (figure 2)
3. Repeat for all 3 units

**Component C - Interior column separators** - 4 units

1. Place brown side up
2. Fold in half so that both exposed sides are white (figure 3)
3. Repeat for all 4 units

**Partition Assembly** (using components B and components C)

1. Initially working with 1 component B and 1 component C
2. Place component C with slotted end pointing up and low end of angle towards you
3. Insert component B into C (figure 4)
  - a. Making certain that the front panel of C1 slides into slot 1 of B1 and the back panel of C1 slides into slot 2 of B1
4. Repeat the process with a second component B (figure 5)
  - a. Making certain that the front panel of the 2nd C1 slides into slot 2 of B2 and the back panel of the 2nd C1 slides into slot 3 of B2
5. Repeat the process with a second component B (figure 6)
  - a. Making certain that the front panel of the 3rd C1 slides into slot 3 of B3 and the back panel of the 3rd C1 slides into slot 4 of B3
6. Following the positioning of the component Bs, repeat the inserting of the remaining component Cs to complete the Partition Assembly (figure 7)

### Cadet Pamphlet Distributor Final Assemble

Once the Partition is fully assembled, slide into Component A and stock the 9 compartments with the Cadet information pieces.

