INSPECTION PRE-TRIP VEHICLE

DAILY:

- \$ Fluid level in engine / power steering / hydraulics / brake / clutch / coolant - if applicable;
- All engine belts / hoses for leaks and wear;
- \$\$\$\$\$\$\$\$\$ Tires for cuts / pressure / loose nuts / rims / wear;
- All lights are clean and working:
- Brake and clutch operation;
- Visible leaks around and under the vehicle:
- Start engine / check all gauges and instruments / horn / back up alarm;
- Glass and body for damage;
- Windshield wipers / fluid;
- Check for unusual noises;

Note: Daily items should be checked by the driver of the vehicle.

WEEKLY:

- \$ Transmission / differential / transfer case / gear boxes / hydraulic system for fluid level and leaks, if applicable;
- \$\$\$\$\$ Battery fluid / terminals / cables;
- Loose bolts / loose or bare wires;
- Exhaust system for looseness and leaks / springs;
- Air filter / connections:

Note: Weekly items should be checked by individual assigned the responsibility for the repairs and general maintenance of the vehicle.

IMPORTANT REMINDER

If you are traveling outside the Province, verify if there are specific requirements, special permits and/or the need to complete a logbook (depending on the size of the vehicle).