

e) Lower Lacombe Member

- C39 Depth to Top of Lower Lacombe Member
- C40 Structure-Contour Map - Lower Lacombe Member
- C41 Non-Pumping Water-Level Surface - Lower Lacombe Aquifer
- C42 Apparent Yield for Water Wells Completed through Lower Lacombe Aquifer
- C43 Total Dissolved Solids in Groundwater from Lower Lacombe Aquifer
- C44 Sulfate in Groundwater from Lower Lacombe Aquifer
- C45 Chloride in Groundwater from Lower Lacombe Aquifer
- C46 Fluoride in Groundwater from Lower Lacombe Aquifer
- C47 Piper Diagram - Lower Lacombe Aquifer

f) Haynes Member

- C48 Depth to Top of Haynes Member
- C49 Structure-Contour Map - Haynes Member
- C50 Non-Pumping Water-Level Surface - Haynes Aquifer
- C51 Apparent Yield for Water Wells Completed through Haynes Aquifer
- C52 Total Dissolved Solids in Groundwater from Haynes Aquifer
- C53 Sulfate in Groundwater from Haynes Aquifer
- C54 Chloride in Groundwater from Haynes Aquifer
- C55 Fluoride in Groundwater from Haynes Aquifer
- C56 Piper Diagram - Haynes Aquifer

g) Upper Scollard Formation

- C57 Depth to Top of Upper Scollard Formation
- C58 Structure-Contour Map - Upper Scollard Formation
- C59 Non-Pumping Water-Level Surface - Upper Scollard Aquifer
- C60 Apparent Yield for Water Wells Completed through Upper Scollard Aquifer
- C61 Total Dissolved Solids in Groundwater from Upper Scollard Aquifer
- C62 Sulfate in Groundwater from Upper Scollard Aquifer
- C63 Chloride in Groundwater from Upper Scollard Aquifer
- C64 Fluoride in Groundwater from Upper Scollard Aquifer
- C65 Piper Diagram - Upper Scollard Aquifer

h) Lower Scollard Formation

- C66 Depth to Top of Lower Scollard Formation
- C67 Structure-Contour Map - Lower Scollard Formation
- C68 Non-Pumping Water-Level Surface - Lower Scollard Aquifer
- C69 Apparent Yield for Water Wells Completed through Lower Scollard Aquifer
- C70 Total Dissolved Solids in Groundwater from Lower Scollard Aquifer
- C71 Sulfate in Groundwater from Lower Scollard Aquifer
- C72 Chloride in Groundwater from Lower Scollard Aquifer
- C73 Fluoride in Groundwater from Lower Scollard Aquifer

i) Battle Formation

- C74 Depth to Top of Battle Formation
- C75 Structure-Contour Map - Battle Formation

j) Upper Horseshoe Canyon Formation

- C76 Depth to Top of Upper Horseshoe Canyon Formation
- C77 Structure-Contour Map - Upper Horseshoe Canyon Formation
- C78 Non-Pumping Water-Level Surface - Upper Horseshoe Canyon Aquifer
- C79 Apparent Yield for Water Wells Completed through Upper Horseshoe Canyon Aquifer
- C80 Total Dissolved Solids in Groundwater from Upper Horseshoe Canyon Aquifer
- C81 Sulfate in Groundwater from Upper Horseshoe Canyon Aquifer
- C82 Chloride in Groundwater from Upper Horseshoe Canyon Aquifer
- C83 Fluoride in Groundwater from Upper Horseshoe Canyon Aquifer

k) Middle Horseshoe Canyon Formation

- C84 Depth to Top of Middle Horseshoe Canyon Formation
- C85 Structure-Contour Map - Upper Middle Canyon Formation

4) Hydrographs and Observation Water Wells

- D01 AENV Obs WW

YELLOWHEAD COUNTY

Appendix C

General Water Well Information

Domestic Water Well Testing.....	2
Purpose and Requirements	2
Procedure.....	3
Site Diagrams	3
Surface Details	3
Groundwater Discharge Point	3
Water-Level Measurements	3
Discharge Measurements.....	3
Water Samples	3
Water Act - Water (Ministerial) Regulation	4
Chemical Analysis of Farm Water Supplies.....	5
Additional Information	9

Domestic Water Well Testing

Purpose and Requirements

The purpose of the testing of domestic water wells is to obtain background data related to:

- 1) the non-pumping water level for the aquifer - Has there been any lowering of the level since the last measurement?
- 2) the specific capacity of the water well, which indicates the type of contact the water well has with the aquifer;
- 3) the transmissivity of the aquifer and hence an estimate of the projected long-term yield for the water well;
- 4) the chemical, bacteriological and physical quality of the groundwater from the water well.

The testing procedure involves conducting an aquifer test and collecting of groundwater samples for analysis by an accredited laboratory. The date and time of the testing are to be recorded on all data collection sheets. A sketch showing the location of the water well relative to surrounding features is required. The sketch should answer the question, "If this water well is tested in the future, how will the person doing the testing know this is the water well I tested?"

The water well should be taken out of service as long as possible before the start of the aquifer test, preferably not less than 30 minutes before the start of pumping. The non-pumping water level is to be measured 30, 10, and 5 minutes before the start of pumping and immediately before the start of pumping which is to be designated as time 0 for the test. All water levels must be from the same designated reference, usually the top of the casing. Water levels are to be measured during the pumping interval and during the recovery interval after the pump has been turned off; all water measurements are to be with an accuracy of ± 0.01 metres.

During the pumping and recovery intervals, the water level is to be measured at the appropriate times. An example of the time schedule for a four-hour test is as follows, measured in minutes after the pump is turned on and again after the pump is turned off:

1,2,3,4,6,8,10,13,16,20,25,32,40,50,64,80,100,120.

For a four-hour test, the reading after 120 minutes of pumping will be the same as the 0 minutes of recovery. Under no circumstance will the recovery interval be less than the pumping interval.

Flow rate during the aquifer test should be measured and recorded with the maximum accuracy possible. Ideally, a water meter with an accuracy of better than $\pm 1\%$ displaying instantaneous and total flow should be used. If a water meter is not available, then the time required to completely fill a container of known volume should be recorded, noting the time to the nearest 0.5 seconds or better. Flow rate should be determined and recorded often to ensure a constant pumping rate.

Groundwater samples should be collected as soon as possible after the start of pumping and within 10 minutes of the end of pumping. Initially only the groundwater samples collected near the end of the pumping interval need to be submitted to the accredited laboratory for analysis. All samples must be properly stored for transportation to the laboratory and, in the case of the bacteriological analysis, there is a maximum time allowed between the time the sample is collected and the time the sample is delivered to the laboratory. The first samples collected are only analyzed if there is a problem or a concern with the first samples submitted to the laboratory.

Procedure

Site Diagrams

These diagrams are a map showing the distance to nearby significant features. This would include things like a corner of a building (house, barn, garage etc.) or the distance to the half-mile or mile fence. The description should allow anyone not familiar with the site to be able to unequivocally identify the water well that was tested. In lieu of a map, UTM coordinates accurate to within five metres would be acceptable. If a hand-held GPS is used, the post-processing correction details must be provided.

Surface Details

The type of surface completion must be noted. This will include such things as a pitless adapter, well pit, pump house, in basement, etc. Also, the reference point used for measuring water levels needs to be noted. This would include top of casing (TOC) XX metres above ground level; well pit lid, XX metres above TOC; TOC in well pit XX metres below ground level.

Groundwater Discharge Point

Where was the flow of groundwater discharge regulated? For example was the discharge through a hydrant downstream from the pressure tank; discharged directly to ground either by connecting directly above the well seal or by pulling the pump up out of the pitless adapter; from a tap on the house downstream from the pressure tank? Also note must be made if any action was taken to ensure the pump would operate continuously during the pumping interval and whether the groundwater was passing through any water-treatment equipment before the discharge point.

Water-Level Measurements

How were the water-level measurements obtained? If obtained using a contact gauge, what type of cable was on the tape, graduated tape or a tape with tags? If a tape with tags, when was the last time the tags were calibrated? If a graduated tape, what is the serial number of the tape and is the tape shorter than its original length (i.e. is any tape missing)?

If water levels are obtained using a transducer and data logger, the serial numbers of both transducer and data logger are needed and a copy of the calibration sheet. The additional information required is the depth the transducer was set and the length of time between when the transducer was installed and when the calibration water level was measured, plus the length of time between the installation of the transducer and the start of the aquifer test. All water levels must be measured at least to the nearest 0.01 metres.


Discharge Measurements

Type of water meter used. This could include such things as a turbine or positive displacement meter. How were the readings obtained from the meter? Were the readings visually noted and recorded or were they recorded using a data logger?

Water Samples

A water sample must be collected between the 4- and 6-minute water-level measurements, whenever there is an observed physical change in the groundwater being pumped, and 10 minutes before the end of the planned pumping interval. Additional water samples must be collected if it is expected that pumping will be terminated before the planned pumping interval.

Water Act - Water (Ministerial) Regulation



PROVINCE OF ALBERTA

WATER ACT

**WATER (MINISTERIAL)
REGULATION**

Alberta Regulation 205/98

EXTRACT FROM THE
ALBERTA GAZETTE

© Published by
the Queen's Printer for Alberta

Queen's Printer Bookstore
11510 Kingsway
Edmonton, AB T5G 2Y5
(403) 427-4952
Fax: (403) 452-0668
Note: After Jan. 25/99 use area code (780)

Queen's Printer Bookstore
Main Floor, McDougall Centre
455 - 6th Street S.W.
Calgary, AB T2P 4E8
(403) 297-6251
Fax: (403) 297-8450

Shop On-line at <http://www.gov.ab.ca/qp>

ALBERTA REGULATION 205/98

Water Act

WATER (MINISTERIAL) REGULATION

Table of Contents

Interpretation	1
Part 1 Activities	
Approval exemption	2
Approval exemptions subject to Code	3
Notice of section 3 activities	4
Part 2 Diversions and Transfers	
Licence exemption	5
Temporary diversions subject to Code	6
Section 6 temporary diversion notices	7
Diversion for household purposes prohibited	8
Subdivisions requiring reports	9
Major river basin boundaries	10
Licence purposes	11
Licence expiry dates	12
Part 3 Notice	
Notice of application, decision or order	13
Exemptions from notice requirements	14
Part 4 Access to Information	
Disclosure of information	15
Provision of information	16
Extension of time	17
Part 5 Land Compensation Board Procedures	
Appeals	18
Notice of appeal	19
Pre-hearing matters	20
Conduct of a hearing and decision	21
Combining hearings	22
Costs	23
Fees	24
Extension of time	25

Chemical Analysis of Farm Water Supplies

Adapted from Agdex 716 (D04) Published April 1991

A routine chemical analysis tests the water for 15 chemical parameters. It will reveal the hardness and iron concentration as well as the presence of other chemicals such as chlorides, sulphates, nitrates and nitrites. Chemicals, other than those listed below, can be tested but arrangements should be made with the lab before the sample is submitted. These special requests' must be clearly specified on the request form. Your farm water supply should be analyzed whenever a new water source is constructed, or when a change in water quality is noticed.

Your local health unit can provide you with the necessary water sample containers. Water samples specifically for human consumption must be submitted to the health unit.

The water sample you take should be representative. Choose an outlet as close to the source as possible. For most domestic samples, allow the water to run through the faucet for about five minutes and then fill the sample container.

Once you have obtained a good water sample, take it to your local health unit for forwarding to the appropriate laboratory. After the laboratory analysis is completed, the health inspector or technologist will receive a copy of the analysis and will be able to help you interpret the results.

Water Quality Criteria

It is not essential for private supplies to meet these guidelines. People have different reactions and tolerances to different minerals. If any chemical in your water exceeds drinking water limits consult your family doctor or local health unit.

All levels listed below (except pH) are listed in parts per million (ppm). Many labs report results in milligrams/Litre (mg/L), which is equivalent to ppm.

Sodium

Sodium is not considered a toxic metal, and 5,000 to 10,000 milligrams per day are consumed by normal adults without adverse effects. The average intake of sodium from water is only a small fraction of that consumed in a normal diet.

Persons suffering from certain medical conditions such as hypertension may require a sodium restricted diet, in which case the intake of sodium from drinking water could become significant. Sodium levels as low as 20 ppm are sometimes a concern to them. A maximum level of 300 (200*) ppm sodium has traditionally been used as a guideline but the "Guidelines for Canadian Drinking Water Quality" list no maximum acceptable concentration.

Sodium is a significant factor in assessing water for irrigation and plant watering. High sodium levels affect soil structure and a plant's ability to take up water.

Potassium

Potassium is usually only found in quantities of a few ppm in water. There is no recommended limit for potassium but levels over 2,000 ppm may be harmful to human nervous systems. Alberta water supplies rarely contain more than 20 ppm.

Calcium

Calcium is one cause of "hardness" in water. Calcium is not a hazard to health but is undesirable because it may be detrimental for domestic uses such as washing, bathing and laundering. It also tends to cause encrustations in kettles, coffee makers and water heaters. 200 ppm is often considered an acceptable limit.

Magnesium

Magnesium is another constituent causing "hardness" in water. A suggested limit of 150 ppm is used because of taste considerations.

Iron

Iron levels as low as 0.2 to 0.3 ppm will usually cause the staining of laundry and plumbing fixtures. The presence of iron bacteria in water supplies will often cause these symptoms at even lower levels. Iron gives water a metallic taste that may be objectionable to some persons at one to two ppm. Most water contains less than five ppm iron but occasionally levels over 30 ppm are found. Iron and iron bacteria are not considered a health concern.

Sulphate (SO₄)

Sulphate concentrations over 500 ppm can be laxative to some humans and livestock. Sulphate levels over 500 ppm may be a concern for livestock on marginal intakes of certain trace minerals. Very high levels of sulphates have been associated with some brain disorders in cattle and pigs.

Chloride

Due to taste considerations the suggested maximum level for chloride is 250 ppm. Most water in Alberta contains less than 20 ppm chloride, although chloride in the 2,000 ppm range can be found.

NO₂ Nitrogen (Nitrite)

Due to its toxicity, the maximum acceptable concentration of nitrite in drinking water is one ppm. Nitrite is usually an indicator of very direct contamination by sewage or manure because nitrites are unstable and quickly become nitrates.

The concentration in livestock water should not exceed 10 ppm.

NO₃ Nitrogen (Nitrate)

Nitrates are also an indicator of contamination by human or livestock wastes, excessive fertilization or seepage from dump sites. The maximum acceptable concentration in drinking water is 10 ppm. The figure is based on the potential for the nitrate poisoning of infants. Adults can tolerate higher levels but high nitrate levels may cause irritation of the stomach and bladder. The suggested maximum for livestock use is 1,000 ppm.

Fluoride

Fluorides occur naturally in most well waters and are desirable since they help prevent dental cavities. Between one and 1.5 ppm is desirable. As fluoride levels increase above this amount there is an increase in the tendency to cause tooth mottling.

Fluoride levels less than four ppm are not considered a problem for livestock.

TDS Inorganic (Total Dissolved Solids)

This is a measure of the inorganic minerals dissolved in the water. As a general rule less than 1,000 (500*) ppm TDS is considered satisfactory. Levels higher than this are not necessarily a problem; it depends on the specific minerals present.

The suitability for livestock deteriorates as TDS exceeds the 2,000 to 3,000 ppm range.