

g) Oldman Formation

Depth to Top of Oldman Formation
Structure-Contour Map - Oldman Formation
Non-Pumping Water-Level Surface - Oldman Aquifer
Apparent Yield for Water Wells Completed through Oldman Aquifer
Total Dissolved Solids in Groundwater from Oldman Aquifer
Sulfate in Groundwater from Oldman Aquifer
Chloride in Groundwater from Oldman Aquifer
Fluoride in Groundwater from Oldman Aquifer
Piper Diagram - Oldman Aquifer
Recharge/Discharge Areas between Surficial Deposits and Oldman Aquifer

h) Foremost Formation

Depth to Top of Foremost Formation
Structure-Contour Map - Foremost Formation
Non-Pumping Water-Level Surface - Foremost Aquifer
Apparent Yield for Water Wells Completed through Foremost Aquifer
Total Dissolved Solids in Groundwater from Foremost Aquifer
Sulfate in Groundwater from Foremost Aquifer
Chloride in Groundwater from Foremost Aquifer
Fluoride in Groundwater from Foremost Aquifer
Piper Diagram - Foremost Aquifer
Recharge/Discharge Areas between Surficial Deposits and Foremost Aquifer

i) Lea Park Formation

Depth to Top of Lea Park Formation
Structure-Contour Map - Lea Park Formation

j) Milk River Formation

Depth to Top of Milk River Formation
Structure-Contour Map - Milk River Formation
Non-Pumping Water-Level Surface - Milk River Aquifer
Apparent Yield for Water Wells Completed through Milk River Aquifer
Recharge/Discharge Areas between Surficial Deposits and Milk River Aquifer

4) Hydrographs and Observation Water Wells

Location of AENV Observation Water Wells
Hydrographs North
Hydrographs South
Annual Precipitation vs. Water Levels in AENV Obs WW No. 114
Annual Precipitation vs. Water Levels in AENV Obs WW No. 107
Monthly Temperature and Winter Precipitation vs. Water Levels in AENV Obs WW No. 107
Monthly Temperature and Winter Precipitation vs. Water Levels in AENV Obs WW No. 93
PFRA Windmill WSW Water Levels vs. WSW No. 3-98 Groundwater Production

5) Specific Study Areas

Specific Study Areas
Paetku Spring - Flow-Rate Measurements
Elkwater Lake Mean Monthly Water Levels vs. Annual Precipitation

CYPRESS COUNTY

Appendix C

General Water Well Information

Domestic Water Well Testing	2
Purpose and Requirements	2
Procedure	3
Site Diagrams	3
Surface Details	3
Groundwater Discharge Point	3
Water-Level Measurements	3
Discharge Measurements	3
Water Samples	3
Water Act - Water (Ministerial) Regulation	4
Water Act – Flowchart	5
Interpretation of Chemical Analysis of Drinking Water	6
Additional Information	8

Domestic Water Well Testing

Purpose and Requirements

The purpose of the testing of domestic water wells is to obtain background data related to:

- 1) the non-pumping water level for the aquifer - Has there been any lowering of the level since the last measurement?
- 2) the specific capacity of the water well, which indicates the type of contact the water well has with the aquifer;
- 3) the transmissivity of the aquifer and hence an estimate of the projected long-term yield for the water well;
- 4) the chemical, bacteriological and physical quality of the groundwater from the water well.

The testing procedure involves conducting an aquifer test and collecting of groundwater samples for analysis by an accredited laboratory. The date and time of the testing are to be recorded on all data collection sheets. A sketch showing the location of the water well relative to surrounding features is required. The sketch should answer the question, "If this water well is tested in the future, how will the person doing the testing know this is the water well I tested?"

The water well should be taken out of service as long as possible before the start of the aquifer test, preferably not less than 30 minutes before the start of pumping. The non-pumping water level is to be measured 30, 10, and 5 minutes before the start of pumping and immediately before the start of pumping which is to be designated as time 0 for the test. All water levels must be from the same designated reference, usually the top of the casing. Water levels are to be measured during the pumping interval and during the recovery interval after the pump has been turned off; all water measurements are to be with an accuracy of ± 0.01 metres.

During the pumping and recovery intervals, the water level is to be measured at the appropriate times. An example of the time schedule for a four-hour test is as follows, measured in minutes after the pump is turned on and again after the pump is turned off:

1,2,3,4,6,8,10,13,16,20,25,32,40,50,64,80,100,120.

For a four-hour test, the reading after 120 minutes of pumping will be the same as the 0 minutes of recovery. Under no circumstance will the recovery interval be less than the pumping interval.

Flow rate during the aquifer test should be measured and recorded with the maximum accuracy possible. Ideally, a water meter with an accuracy of better than $\pm 1\%$ displaying instantaneous and total flow should be used. If a water meter is not available, then the time required to completely fill a container of known volume should be recorded, noting the time to the nearest 0.5 seconds or better. Flow rate should be determined and recorded often to ensure a constant pumping rate.

Groundwater samples should be collected as soon as possible after the start of pumping and within 10 minutes of the end of pumping. Initially only the groundwater samples collected near the end of the pumping interval need to be submitted to the accredited laboratory for analysis. All samples must be properly stored for transportation to the laboratory and, in the case of the bacteriological analysis, there is a maximum time allowed between the time the sample is collected and the time the sample is delivered to the laboratory. The first samples collected are only analyzed if there is a problem or a concern with the first samples submitted to the laboratory.

Procedure

Site Diagrams

These diagrams are a map showing the distance to nearby significant features. This would include things like a corner of a building (house, barn, garage etc.) or the distance to the half-mile or mile fence. The description should allow anyone not familiar with the site to be able to unequivocally identify the water well that was tested. In lieu of a map, UTM coordinates accurate to within five metres would be acceptable. If a hand-held GPS is used, the post-processing correction details must be provided.

Surface Details

The type of surface completion must be noted. This will include such things as a pitless adapter, well pit, pump house, in basement, etc. Also, the reference point used for measuring water levels needs to be noted. This would include top of casing (TOC) XX metres above ground level; well pit lid, XX metres above TOC; TOC in well pit XX metres below ground level.

Groundwater Discharge Point

Where was the flow of groundwater discharge regulated? For example was the discharge through a hydrant downstream from the pressure tank; discharged directly to ground either by connecting directly above the well seal or by pulling the pump up out of the pitless adapter; from a tap on the house downstream from the pressure tank? Also note must be made if any action was taken to ensure the pump would operate continuously during the pumping interval and whether the groundwater was passing through any water-treatment equipment before the discharge point.

Water-Level Measurements

How were the water-level measurements obtained? If obtained using a contact gauge, what type of cable was on the tape, graduated tape or a tape with tags? If a tape with tags, when was the last time the tags were calibrated? If a graduated tape, what is the serial number of the tape and is the tape shorter than its original length (i.e. is any tape missing)?

If water levels are obtained using a transducer and data logger, the serial numbers of both transducer and data logger are needed and a copy of the calibration sheet. The additional information required is the depth the transducer was set and the length of time between when the transducer was installed and when the calibration water level was measured, plus the length of time between the installation of the transducer and the start of the aquifer test. All water levels must be measured at least to the nearest 0.01 metres.


Discharge Measurements

Type of water meter used. This could include such things as a turbine or positive displacement meter. How were the readings obtained from the meter? Were the readings visually noted and recorded or were they recorded using a data logger?

Water Samples

A water sample must be collected between the 4- and 6-minute water-level measurements, whenever there is an observed physical change in the groundwater being pumped, and 10 minutes before the end of the planned pumping interval. Additional water samples must be collected if it is expected that pumping will be terminated before the planned pumping interval.

Water Act - Water (Ministerial) Regulation



ALBERTA REGULATION 205/98


Water Act

WATER (MINISTERIAL) REGULATION

Table of Contents

Interpretation	1
Part 1 Activities	
Approval exemption	2
Approval exemptions subject to Code	3
Notice of section 3 activities	4
Part 2 Diversions and Transfers	
Licence exemption	5
Temporary diversions subject to Code	6
Section 6 temporary diversion notices	7
Diversion for household purposes prohibited	8
Subdivisions requiring reports	9
Major river basin boundaries	10
Licence purposes	11
Licence expiry dates	12
Part 3 Notice	
Notice of application, decision or order	13
Exemptions from notice requirements	14
Part 4 Access to Information	
Disclosure of information	15
Provision of information	16
Extension of time	17
Part 5 Land Compensation Board Procedures	
Appeals	18
Notice of appeal	19
Pre-hearing matters	20
Conduct of a hearing and decision	21
Combining hearings	22
Costs	23
Fees	24
Extension of time	25

Water Act – Flowchart



MOW-TECH LTD.
Your Groundwater Source
1 800 661 6061
© 1999 Mow-Tech Ltd.

This flow chart was developed by Mow-Tech Ltd. and is provided as a guide **only** to Alberta's new **Water Act**. Mow-Tech Ltd. accepts no responsibility for the information provided.



Interpretation of Chemical Analysis of Drinking Water



Stony Plain - Lac Ste. Anne Health Unit

HEAD OFFICE
P.O. Box 210
Stony Plain, Alberta
Canada T0E 2G0
Telephone: 963-2206
Fax: 963-7612

SUB-OFFICES
Box 4323
Spruce Grove, Alberta
T7X 3B5
Telephone: 962-4072

163 Provincial Bldg.
Whitecourt, Alberta
T0E 2L0
Telephone: 778-5555
Fax: 778-3852

Box 430
Fox Creek, Alberta
T0H 1P0
Telephone: 622-3730

HOME CARE:
Box 210
Stony Plain, Alberta
T0E 2G0
Telephone: 963-3366

INTERPRETATION OF CHEMICAL ANALYSIS OF DRINKING WATER

1. TOTAL DISSOLVED SOLIDS (TDS) - The recommended limit is 1000 mg/L for untreated and 500 mg/L for treated waters. TDS indicates the approximate organic and inorganic substances in the water. It will be high if other components of the analysis are high.
2. IRON - Amounts over 0.3 mg/L, usually stain laundry and plumbing fixtures and cause undesirable tastes. Iron filtration can be utilized. Iron bacteria may also be the cause of increased iron content.
3. CALCIUM - This is a constituent of hardness. Excessive calcium in drinking water may be a factor in disorders of the kidneys, bladder and urinary system.
4. MAGNESIUM - This is a constituent of hardness.
5. HARDNESS - A maximum acceptable concentration has not been established. Hardness is caused mainly by calcium and magnesium. Levels between 80 and 100 mg/L are satisfactory; 100 to 200 mg/L are less acceptable; more than 200 mg/L are considered to be poor and in excess of 500 mg/L are unacceptable for most domestic purposes. Softening can be helpful in given circumstances.
6. SODIUM - Ideally, there should be no more than 200mg/L. The average intake of sodium from water is only a small fraction of that consumed in a normal diet. Persons suffering from hypertension or congestive heart failure may require a sodium-restricted diet, in which case the intake of sodium from drinking water could become significant. Your physician should be informed of the sodium content.
7. NITRITE-NITROGEN & NITRATE-NITROGEN (NO₂ + NO₃) - The maximum acceptable concentration is 10 mg/L. Any amount over that may be harmful to children up to 12 months of age, causing a condition known as methaemoglobinaemia. Presence may indicate a contaminating source although other instances, e.g. fertilizer and decomposing vegetation can cause an elevated figure.
8. NITRITE-NITROGEN - The maximum acceptable concentration is 1.0 Mg/L. Nitrite is unstable in water and converts to nitrate. An elevated figure may indicate a pollution problem.
9. FLUORIDE - Approximately 1 mg/L of fluoride is recommended in drinking water in order to give developing teeth some protection against decay. If the fluoride is higher than 1.5 mg/L you should talk to the dental staff of the Health Unit about the possibility of mottled enamel; if the fluoride is lower than 0.7 mg/L please ask about fluoride supplements for your children.
10. SULPHATE - The maximum acceptable concentration is 500 mg/L. Taste becomes noticeable between 250 and 600 mg/L and a laxative effect may be noticed by new users when sulphate combines with sodium or magnesium.